

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☒ gas well ☐ other ☐

2. NAME OF OPERATOR
Grace Petroleum Corporation

3. ADDRESS OF OPERATOR
143 Union Blvd - Ste 760, Lakewood, CO 80228

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 485' FSL, 1945' FEL Sec. 33
AT TOP PROD. INTERVAL: same
AT TOTAL DEPTH: same

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☒
(other) ☐

SUBSEQUENT REPORT OF:

☐
☐
☐
☐
☐
☐
☐
☐
☐

RECEIVED

OCT 19 1984

(NOTE: Report results of multiple completion or zone change on Form 9-330.)
BUREAU OF LAND MANAGEMENT
HARMINGTON RESOURCE AREA

5. LEASE

SF-080107-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Barin Shawnee

9. WELL NO.

8341

10. FIELD OR WILDCAT NAME

Escrito-Lybrook

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Section 33, T24N-R7W

12. COUNTY OR PARISH

Rio Arriba

13. STATE

New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
7374' GL

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Proposal: Plug and abandon well #33-1 as follows:

1. Kill well w/lease water.
2. Squeeze perfs (5959'-6076') w/100 sx Class 'G' cmt.
3. Role hole w/±92 bbls 9.2 ppg mud.
4. Perforate 8 squeeze holes @ 3900'-02' and squeeze w/50 sx Class 'G' cmt.
5. Perforate 8 squeeze holes @ 2850'-02' and squeeze w/50 sx Class 'G' cmt.
6. Spot a 19 sx Class 'G' cmt surface plug in 4-1/2" from 280' to surface.
7. Pump 30 sx Class 'G' plug through Bradenhead down 8-5/8" x 4-1/2" annulus.
8. Install permanent monument.
9. Clean-up and restore location.

Subsurface Safety Valve: Manu. and Type

Set @ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED James E. Johnson

TITLE Dist. Operations Mgr

DATE

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

OCT 23 1984

FOR A. MILLENBACH
AREA MANAGER

BUREAU OF LAND MANAGEMENT
Caller Service 4104
Farmington, New Mexico 87499

Attachment to Notice of
Intention to Abandon

Re: Permanent Abandonment
Well: 1 Shawnee

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases."
2. The Farmington office (telephone (505) 325-4572) is to be notified in sufficient time for a representative to witness all plugging operations.
3. Blowout prevention equipment is required.
4. In addition to normal filling of pits and cleanup of location, additional surface restoration work may be required, i.e. ripping of pad and/or access road, reseeding, etc. We have asked the Surface Management Agency for the surface restoration requirements for this well and we should be able to furnish you these requirements within 30 days. After plugging the well and before making final clean-up, you should contact this office unless you have already been advised as to what additional surface restoration work is required.
5. The following modifications to your plugging program are to be made (when applicable):
 - A) Squeeze existing perforations leaving sufficient cement inside 4 1/2" csg. to cover the Gallup Fm. to 5740
 - B) Perforate and squeeze @ 3950', fill inside and outside of 4 1/2" csg. to cover the interval 3950' - 3850'.
 - C) Perforate and squeeze Pictured Cliffs Fm. @ 2480', fill inside and outside of the 4 1/2" csg. to cover the interval 2480' to 2380'.
 - D) Perforate and squeeze @ 1980' (50' below the Ojo Alamo) fill inside and outside of 4 1/2" csg. to cover the interval 1980' to 1718'.

You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to technical and procedural review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.

Office Hours: 7:45 A.M. to 4:30 P.M.

GENERAL REQUIREMENTS FOR
PERMANENT ABANDONMENT OF WELLS ON FEDERAL LEASES
FARMINGTON RESOURCE AREA

1. Secure prior approval before changing the approved plugging program.
2. Plugging equipment used shall have separate mixing and displacement pumps and a calibrated tank to assure proper displacement of plugs.
3. A proper tank or pit will be used to contain all fluids pumped from the well during plugging operations.
4. All cement plugs are to be placed through tubing (or drillpipe) and shall be a minimum of 15 sacks or 100 feet in length, whichever is greater.
5. Any cement plug placed when well is not full of fluid, or when well may be taking fluid, will be touched after cement has set to verify proper location.
6. Mud must be placed between plugs. Minimum consistency of plugging mud must be 9.2 lbs/gal. Brine is to be utilized for mixing mud where possible.
7. Within 30 days after plugging work is completed, file Subsequent Report of Abandonment, Form 3160-5 (formerly 9-331), in quintuplicate with Area Manager, Bureau of Land Management, Caller Service 4104, Farmington, New Mexico 87499. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
8. All permanently abandoned wells are to be marked with a permanent monument, on which has been stenciled or beaded the well name, well number, and well location by quarter-quarter, section, township and range. The monument is to be of steel pipe, not less than four inches in diameter, cemented permanently in the ground, and extending four feet above general ground level. The top should be closed with a screw cap, welding, or a cement plug.
9. After plugging work is completed:
 - a. Fill all pits, rat hole and cellar.
 - b. Clean well location of all equipment, concrete bases, pipe, junk and
 - c. Cut or remove tie downs.
 - d. If last well on lease, and no additional drilling is contemplated, fill tank battery pits, remove battery equipment, and clean and level battery location.
 - e. Accomplish surface restoration as specified by the surface management agency or land owner.

All above are minimum requirements. The Subsequent Report of Abandonment will not be approved and the period of liability under the bond of record terminated until the lease is inspected and surface work approved.

Please advise this office when the well location is ready for final inspection.

You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to technical and procedural review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.