Form 3160-5 (June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

FORM	APPR	OVE	SD CE	
Budget Bur	cau No.	100	34- 013	35
Expires:	March	31,	1993	

Bu	kiget Bur	cam No.	1004	0135
	Expires:	March	31, 199	3
Lease	Designat	ion and	Serial	No.

· · - · · · · · · · · · · · · · · ·	S AND REPORTS ON WELLS	Contract No. 36 6. If Indian, Allottee or Tribe Name
Do not use this form for proposals to Use "APPLICATION F	drill or to deepen or reentry to a different reservoir. OR PERMIT—" for such proposals	
	Ott Ethin Tor such proposals	Jicarilla Apache 7. If Unit or CA, Agreement Designation
	IT IN TRIPLICATE	7. If Unit of CA, Agreement Designation
1. Type of Well Oil W Gax		
Util X Well Other 2. Name of Operator		8. Well Name and No.
Conoco Inc.		NE Haynes No. 11Y
3. Address and Telephone No.		30-039-22595
3817 N.W. Expressway, Oklahoma City	OK 73112 (405) 948-3100	10. Field and Pool, or Exploratory Area
4. Location of Well (Footage, Sec., T., R., M., or Survey	Description)	Otera Ranch Pictured Cliffs
905' FSL & 1050' FWL (SE NE SW S	w)	11. County or Parish, State
Sec. 15-24N-5W		
		Rio Arriba NM
12. CHECK APPROPRIATE BOX	((s) TO INDICATE NATURE OF NOTICE, REPOF	RT, OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACTION	
Notice of Intent .	Abandonment	Change of Plans
_ & \(\mathbb{\bar{\pi}}	Recompletion	New Construction
Subvequent Report	Plugging Back	Non-Routine Fracturing
	Casing Repair	Water Shut-Off
Final Abandonment Notice	Altering Casing	Conversion to Injection
— — · (/)	X Other Revised Plugging Procedure	Dispose Water
Please see attached: REVISED PLUGGIN	all pertinent details, and give pertinent dates, including estimated date of starting cal depths for all markers and zones pertinent to this work.)*	(Note: Report results of multiple completion on Well Completion or Report picture Report and Los form)
13. Describe Progosed or Completed Operations (Clearly state a give subsurface locations and measured and true vertically states are subsurface locations.)	all pertinent details, and give pertinent dates, including estimated date of starting total depths for all markers and zones pertinent to this work.)* G PROCEDURE for referenced well.	(Note: Report results of multiple completion on Well Completion or Report picture Report and Los form)
13. Describe Promoted or Completed Operations (Clearly state a give subsurface locations and measured and true vertically state and true vertically	all pertinent details, and give pertinent dates, including estimated date of starting total depths for all markers and zones pertinent to this work.)* G PROCEDURE for referenced well.	(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) any proposed work. If well is directionally drilled
13. Describe Promoted or Completed Operations (Clearly state a give subsurface locations and measured and true vertically state and true vertically	all pertinent details, and give pertinent dates, including estimated date of starting total depths for all markers and zones pertinent to this work.)* G PROCEDURE for referenced well.	(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) any proposed work. If well is directionally drilled
13. Describe Progned or Completed Operations (Clearly state a give subsurface locations and measured and true vertically state and control of the progness of	all pertinent details, and give pertinent dates, including estimated date of starting cal depths for all markers and zones pertinent to this work.)* G PROCEDURE for referenced well.	(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) any proposed work. If well is directionally drilled
13. Describe Proposed or Completed Operations (Clearly state a give subsurface localisms and measured and true vertility of the state of the proposed of the p	all pertinent details, and give pertinent dates, including estimated date of starting total depths for all markers and zones pertinent to this work.)* G PROCEDURE for referenced well.	(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) any proposed work. If well is directionally drilled

*See Instruction on Reverse Side

Northeast Haynes #11Y

SW, Sec. 15, T24N, R5W Rio Arriba County, New Mexico

P & A Procedure:

- MOL and RUSU. Comply to all NMOCD, BLM rules and regulations. ND wellhead and then NU BOP and stripping head. Test BOP.
- 2. Release tandem packers. Guiberson Hydraulic, and POH with tubing; LD packers and RIH open ended.
- 3. Plug #1 from 2434' to 1532'' with 59 sxs Class B cement; (50' above Ojo Alamo, 50% Excess). POH.
- 4. WOC. RIH and tag cement.
- 5. Plug #2 from top of cement to 330' with approx. 50 sxs Class B cement; POH to 340' and reverse hole clean. POH with tubing.
- Perforate 2 holes at 330', then establish circulation out bradenhead valve. Pump cement down casing until good cement circulates out bradenhead; approx. 50 sxs.
- 7. Cut off wellhead below surface casinghead and install dry hole marker to BLM specs. RD and MCSU.
- 8. Restore location to BLM stipulations.

UNITED STATES DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT FARMINGTON RESOURCE AREA 1235 LA PLATA HIGHWAY FARMINGTON, NEW MEXICO 87401

Attachment to Notice of

Re: Permanent Abandonment

Intention to Abandon

Well: 11 Y Hayes

CONDITIONS OF APPROVAL

- 1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases."
- 2. Wark Kelly with the Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 326-6201.
- 3. Blowout prevention equipment is required.
- 4. The following modifications to your plugging program are to be made (when applicable):

Place a plug from 800-700' outside the 3/2" (asing (Necimiento)

Office Hours: 7:45 a.m. to 4:30 p.m.

GENERAL REQUIREMENTS FOR PERMANENT ABANDONMENT OF WELLS ON FEDERAL AND INDIAN LEASES FARMINGTON RESOURCE AREA

- 1. Secure prior approval either on a Sundry Notice (Form 3160-5) or verbally from the Fluids Drilling & Production Section at this office before changing the approved plugging program.
- 2. Plugging equipment used shall have separate mixing and displacement pumps and a calibrated tank to assure proper displacement of plugs. The Operator is responsible for providing all measuring devices needed to assure proper measurement of materials being used.
- 3. A proper tank or pit will be used to contain all fluids pumped from the well during plugging operations. Unattended pits are to be fenced.
- 4. All cement plugs are to be placed through tubing (or drillpipe) and shall be a minimum of 100 feet in length with 50% excess inside casing or 100% excess when plug is set in open hole or squeezed into perforations. 15.6#/gal slurry weight is to be used when using class B neat cement or when CaCl₂ is used. Use the recommended slurry weight of other type cements when they are used (Class C, Pozzolan etc.).
- be taking fluid, (i.e. across perfs-unless bridge plug or retainer is used, across bad csg., or fresh water formations) will be tagged (touched) after cement has set to verify proper location.
 - Sa. Testing The first plug below the surface plug shall generally be tested by either tagging the plug with the working pipe string, or pressuring to a minimum pump (surface) pressure of 1000 psig, with no more than a 10 percent drop during a 15-minute period (cased hole only). If the integrity of any other plug is questioned, it must be tested in the same manner. Also, any cement plug which is the only isolating medium for a fresh water interval or a zone containing a valuable mineral deposit should be tested by tagging with the drill string.
- 6. Mud must be placed between plugs. Plugging mud is to be made up with a minimum of 15 lbs/bbl of sodium bentonite, and a nonfermenting polymer.

 Minimum consistency of plugging mud must be 9 lbs/gal and with a minimum viscosity of 50 sec/qt. Fresh water is to be utilized for mixing mud.
- 7. Following the placement of a cement plug, the withdrawl rate for at least the length of the cement plug shall not exceed 30 ft/min, in order to minimize the contamination of the plug.

- 8. Within 30 days after plugging work is completed, file a Sundry Notice (Subsequent Report of Abandonment, Form 3160-5), in quintuplicate with Area Manager, Bureau of Land Management, 1235 La Plata Highway, Farmington, NM 87401. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
- 9. All permanently abandoned wells are to be marked with a regulation marker (4" pipe extending 4' above the ground line) containing the information as specified in 43 CFR 3162.6(d). Unless otherwise approved.
- 10. After plugging work is completed the surface is to be rehabilitated in accord with instructions from the Fluids Surface Management Section of the Farmington Resource Area Office.

All above are minimum requirements. The period of liability under the bond of record will not be terminated until the lease is inspected and surface work approved.

Please advise this office when the well location is ready for final inspection.

Failure to comply with the above conditions of approval may result in an assessment for noncompliance and/or a Shut-in Order being issued pursuant to 43 CFR 3163.1.

You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to administrative review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.