

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.
SF 080375B

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.
BOLACK 2

9. API Well No.
030-039-06155

10. Field and Pool, or Exploratory Area
BALLARD PICTURED CLIFFS

11. County or Parish, State
RIO ARRIBA, NEW MEXICO

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator
ROBERT L. BAYLESS

3. Address and Telephone No.
P.O. BOX 168 FARMINGTON, NEW MEXICO 87499 (505) 326-2659

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
1,700FSL 1,190FEL I 06,25N 07W

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

After receiving approval, Bayless will plug and abandon this well using the attached procedure

RECEIVED
APR 15 1997

ON COM. DIV.

14. I hereby certify that the foregoing is true and correct

Signed **[Signature]** Title **Petroleum Engineer** Date **4/4/97**

(This space for Federal or State office use)

Approved by **/s/ Duane W. Spencer** Title _____ Date **APR 14 1997**

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

ROBERT L. BAYLESS
ABANDONMENT PROCEDURE
BOLACK NO. 2
1700' FSL & 1190' FEL, SEC. 6, T25N, R7W
RIO ARriba COUNTY, NM

Formation Tops:

Ojo Alamo: 1335'
Ojo Alamo Base: 1735'
Pictured Cliffs: 2277'

1. Repair road and dig workover pit. Check for rig anchors, if necessary. Haul an extra 2 joints 1 1/4" tubing to location.
2. Move in and rig up pulling unit. Blow well down to pit. Kill well if necessary. Rig up BOP.
3. Pick up extra 1 1/4" tubing and trip in to tag TD at 2384' KB. Trip out and tally 1 1/4" tubing.
4. Trip in with CIBP on tubing to 2230'. Set CIBP. Load hole with water. Spot a 23 sx. Class B cement plug. The top of the plug is to be at 2030'.
5. Trip out laying down to 1790'. Spot an 59 sx Class B cement plug. The top of the plug is to be at 1285'.
6. Trip out and lay down tubing.
7. Trip in and perforate two squeeze holes at 154'. Establish circulation out bradenhead valve. Pump approximately 41 sx Class B cement down 5 1/2" casing; pump cement until good cement returns through bradenhead valve. Shut in the well and wait on cement.
8. Nipple down BOP and cut off wellhead. Install P&A marker pursuant to regulations. Rig down and cut off anchors if necessary. Haul fluids from pit if required.
9. Reclaim pit and restore location as required.