

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well gas ☒ well other ☐
2. NAME OF OPERATOR
Mobil Oil Corporation
3. ADDRESS OF OPERATOR
9 Greenway Plaza, Suite 2700 HoustonTX77046
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 990 FSL & 990 FNL
AT TOP PROD. INTERVAL: same as surface
AT TOTAL DEPTH: same as surface
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

SUBSEQUENT REPORT OF:

- | | | |
|----------------------|--------------------------|--------------------------|
| TEST WATER SHUT-OFF | <input type="checkbox"/> | <input type="checkbox"/> |
| FRACTURE TREAT | <input type="checkbox"/> | <input type="checkbox"/> |
| SHOOT OR ACIDIZE | <input type="checkbox"/> | <input type="checkbox"/> |
| REPAIR WELL | <input type="checkbox"/> | <input type="checkbox"/> |
| PULL OR ALTER CASING | <input type="checkbox"/> | <input type="checkbox"/> |
| MULTIPLE COMPLETE | <input type="checkbox"/> | <input type="checkbox"/> |
| CHANGE ZONES | <input type="checkbox"/> | <input type="checkbox"/> |
| ABANDON* | <input type="checkbox"/> | <input type="checkbox"/> |
- (other) Abandon Pictured Cliffs &
stimulate Mesaverde.

5. LEASE
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
Cheney Federal
9. WELL NO.
2
10. FIELD OR WILDCAT NAME
Blanco Mesaverde
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 17, T26N, R2W
12. COUNTY OR PARISH
Rio Arriba
13. STATE
New Mexico
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
N/A

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRU, kill well
2. P.O.H. w/ 2-3/8 Pictured Cliffs Production string.
3. P.O.H. and lay down 1 1/4" Mesa Verde Production String.
4. R.I.H. w/ Retrievable Bridge Plug on 2-3/8 tbg and set inside 7-5/8" casing at 3835'. Cap w/ sand.
5. P.O.H. w/ setting tool. R.I.H. w/ RTTS packer and set at 3760'.
6. Squeeze the Pictured Cliffs perms (3778-84, 3788-3805) w/ class C neat cement.
7. P.O.H. w/ RTTS tool. RIH w/ bit and drill out cement. Once cement is drilled out, close BOP and pressure test P.C. squeezed perms to 750 PSI.
8. P.O.H. w/ bit. If test ok go to step 9. If test not ok go to step 6.
9. R.I.H. w/ retrieving tool and wash sand off retrievable bridge plug and retrieve. P.O.H.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Robbie Jay TITLE Authorized Agent DATE 11/8/79

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:*ok Smith*

*See Instructions on Reverse Side

