

NOTE: Submit in triplicate

Form Approved.
Budget Bureau No. 42-R1424

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well ☐ gas ☒ well ☐ other

2. NAME OF OPERATOR

Occidental Petroleum, Inc.

3. ADDRESS OF OPERATOR

5000 Stockdale Hwy., Bakersfield, CA

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)

AT SURFACE: 2460' from S. line & 1510'

AT TOP PROD. INTERVAL: from W. line of

AT TOTAL DEPTH: Sec. 6

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

CHANGE ZONES ☐

ABANDON* ☒

(other) ☐

5. LEASE

Contract #152

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Jicarilla Apache

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Jicarilla West

9. WELL NO.

#5

10. FIELD OR WILDCAT NAME

South-Blanco P.C.

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 6, T26N/R5W, NMPM

12. COUNTY OR PARISH 13. STATE

Rio Arriba New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)

6672' G.L.

RECEIVED

JAN 08, 1982

(NOTE: Report results of multi pre completion or zone change on Form 9-331-C)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

See attached program.



Subsurface Safety Valve: Manu. and Type

Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED

J. N. Butcher

TITLE OPERATIONS MGR. DATE 1-4-82

APPROVED BY

CONDITIONS OF APPROVAL IF ANY

APPROVED

James F. Smith
JAN 12 1982

TITLE

DATE

For JAMES F. SMITH
DISTRICT ENGINEER

~~FARMINGTON COPY~~

See Instructions on Reverse Side

NMOCC

ABANDONMENT PROGRAM

Oxy Petroleum, Inc.
Jicarilla West #152
San Juan Basin Field
Well #5
Sec. 6, T26N/R5W

TD = 3425' PSTD = 3390'

Casing: 7-5/8", 26.40#, J-55, 8rd, ST&C, cemented at 171'
2-7/8", 6.5#, J-55, 8rd, EUE cemented at 3422'
2 JHPF at 3273' to 3296' and 3318' to 3328'

Holes in
Casing: Between 1570' to 1792', 1799' to 1806' and 1930' to 1980'

Program: (All depths refer to KB which is 14' above ground level)

1. Move in production rig.
2. Kill well.
3. Release Baker Packer at +3240' and pull out of hole.
4. Run in 12" tubing to effective depth (+3390'), pull up 2' and stage in 31 cubic feet of class G cement slurry to +50' above the Ojo Alamo sand (USGS to witness). ~~Set top at 2290'~~ Log Top 2438'
5. Pull out of hole, wait 4 hours on cement.
6. Tag plug, USGS to witness. If plug top is below Ojo Alamo, then pump in sufficient cement to bring plug to 50' above the Ojo Alamo sand, USGS to witness.
7. Fill to surface with 9.2#/gal. salvaged drilling mud.
8. Perforate 4-1/2" holes at ^{221'}~~175'~~. Run tubing to ^{221'}~~175'~~ and pump cement to surface.
9. Install 4" x 4" marker with company name, well #, section T/R, B&M. Weld steel plate on casing. USGS to witness top hard cement before welding plate on.
10. Clean up well location as per USGS.
11. USGS, BIA to inspect well site.

AKB/tg
12-16-81

cc. TDB ^{gob} MGS
AKB USGS
MAN Coord

OTD