

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

Contract #151

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Jicarilla Tribe

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Arizona Jicarilla "B"

9. WELL NO.

#5

10. FIELD AND POOL, OR WILDCAT

Blanco Mesa Verde

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Section 10, T26N, R5W

12. COUNTY OR PARISH

Rio Arriba

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Southland Royalty Company

3. ADDRESS OF OPERATOR

P.O. Drawer 570, Farmington, NM 8740.

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1840' FWL & 1490' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6915' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREATMENT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose To:

1. Move on location and rig up.
2. Pull rods, pump and 2 3/8" tubing.
3. Spot 50 sacks of cement across Mesa Verde perforations plus 50' above top perf.
4. Take free point and cut off 7 5/8" casing above Pictured Cliffs.
5. Spot 150' plug of cement (approximately 65 sacks of cement) across cut off.
6. Cover Ojo Alamo inside and outside casing plus 50' above the zone if casing is cut above Ojo whose top is at 2882'.
7. Cover entire Ojo Alamo zone plus 50' above zone if casing is cut below this zone.
8. After casing is pulled, spot a 50' plug across surface casing shoe.
9. Spot a 15 sack plug of cement at surface.
10. Install dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE District Production Manager DATE 3-6-79

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

MAR 9 1979

*See Instructions on Reverse Side