Orm 9-331 UNITED STATES SUBMIT IN TRIPLICATE* May 1963) DEPARTMENT OF THE INTERIOR (Other Instructions on regressed) GEOLOGICAL SURVEY						Budget Bureau No. 42-R1424- 5. LEASE DESIGNATION AND SERIAL NO. E.W. Mudge No. 3 SF 078064 6. IF INDIAN, ALLOTTEE OR TRIBE NAME		
SUN (Do not use this	DRY NC	OTICES AND REP	ORTS C	ON WELLS ack to a different reservoir. coposals.)	J. II INDIAN,	ALLO COLLEGE DE LA COLLEGE DE		
1. OIL K GAS WELL OTHER 2. NAME OF OPERATOR						7. UNIT AGREEMENT NAME Carson Unit 8. FARM OR LEASE NAME		
Shell Oil Company 3. ADDRESS OF OPERATOR 1700 Broadway, Denver, Colorado 80202 4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*						9. WELL NO. 41-13 10. FIELD AND POOL, OR WILDCAT		
See also space 17 below.) At surface 660' FNL & 660' FEL of Sec. 13 T25N, R12W NMPM, San Juan Co., N.M.						Bisti 11. SEC. T., E., M., OR BLK. AND SURVEY OR AREA 725N, R12W		
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 6380 K.B.				12. COUNTY O San Jua	n Parish 13. STATE N.M.		
TEST WATER SHUT-0 FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL (Other) 17. DESCRIBE PROPOSED 0 proposed work. I nent to this work.)	R COMPLETED ;	PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON* CHANGE PLANS	X	WATER SHUT-OFF FRACTURE TEEATMENT SHOOTING OR ACIDIZING (Other)	REQUENT REPORT OF REI ALZ ABJ sults of multiple co- completion Report an arts, including estim	FAIRING WELL TERING CASING ANDONMENT* Impletion on Well Id Log form.)		
					COT			

18. I hereby certify that the longuage is true and correct SIGNED		Div Opers	Fnor	**************************************	OCT 0 6 1975
(This space for Pederal or State office use)	TITLE		E	DATE	
APPROVED BY	TITLE			DATE	

Prognosis Plug and Abandonment Carson Unit $41-\overline{13}$ Section 13, T25 N, R12 W San Juan County, New Mexico

Pertinent Data

8-5/8" @ 223

TD: 5050 PBTD: 8-5/8" Csg. @ 233 4-1/2" Csg. @ 5049 w/ 200 sax. 7-7/8" Hole

Past and current status: TA. Shut in 1969

Initial'prod: 77 BO, 1 BW, 0 MCF

Proposed Work: Plug and Abandon

- 1. Pull equipment. If tubing is openended, lower to PBTD, load hole with mud. (Add 20 sax aquagel + 1 sack Benes per 100 bbls of mud or 20 sax salt gel per 100 bbls mud).
- 2. Spot 20 sax Class "G" cement mixed w/l# flocele/sack over perforations and above perforations. Minimum requirements - 100' cement plug above perforations. WOC 12 hrs.
- 3. Pull tubing.
- 4. Rig up casing pullers.
- 5. Attempt to shoot and pull casing at \pm 3500'. (theoretical cement top at 4040. Top of Mancos Shale 3892 . If unable to pull any casing, go to step 8.
- 6. If casing is recovered, run tubing OE and spot Class "G" cement plugs as follows:
 - a. 150' plug across stub of 4-1/2" casing.
 (50' in casing, 100' in open hole)
 - **b.** 200' plug from top of Fruitland Coal at 1170 to 1370.
 - c. 150' plug across base of Ojo Alamo sand at 320 . (100' below base of sand and 50' above base of sand).
 - * d. 230' plug across shoe of 8-5/8" casing. (30' in casing, 200' in open hole).
 - e. 10 sack plug at surface.
- 4-1/2¹¹ (2 5049

4906-19

4923-27

4931-36

4965-68

4979-84

4997-5002

* Provides 100' cement below base of Ojo Alamo.

TD 5050

7. Install permanent abandonment marker as follows:

Steel marker at least 4 inches in diameter set in concrete and extending at least 4' above mean ground level. The name and number of the well and its location (Unit letter, section, township and range) shall be welded, stamped, or otherwise permanently engraved into the metal marker.

- 8. Perforate 4-1/2" casing w/4 JSPF as follows:
 - a. Fruitland Coal Pictures Clifs interval 1190 to 1191.
 - b. Below Ojo Alamo sand from 420 to 421.
- 9. Run tubing, spot a 50 sack (10.3 bbls, 630' in 4-1/2" casing) Class "G" cement plug from $\underline{1190}$ to $\underline{560}$.
- 10. Pull tubing to ± 400 , close bradenhead, displace 20 sax through perforations 1190 to 1191 . WOC hours.
- 11. Pull tubing to perforations 420 to 421.
- 12. Load 4-1/2" casing with cement (\pm 35 sax) and pull tubing. With bradenhead open, displace 20 sax cement through perforations 420 to 421.
- 13. Spot 10 sack plug at surface.
- 14. Install abandonment marker as outlined in step 7.

J. A. Stanzione