Form	9-331	
(May	1963	

(Other)

UNITED STATES

SUBMIT IN TRIPLICATE*

·	Duaget				
L. M.	Phi	1797	IND SI	ERIAL	NO.
710 770			2 110	, a	

DEPARTMENT OF THE INTERIOR verse stee) GEOLOGICAL SURVEY			L. M. Phillips No. 1		
Ob not use this form for proposa	CES AND REPORTS Is to drill or to deepen or plug TION FOR PERMIT—" for such p	back to a different reservoir.	6. IF INDIAN, ALLOTTEE	OR THIRE NAME	
I. OH. X GAS WELL OTHER			7. UNIT AGREEMENT NA Carson Unit		
2. NAME OF OPERATOR			S. FARM OR LEASE NAM	Е	
Shell Oil Company					
3. ADDRESS OF OPERATOR			9. WELL NO.		
1700 Broadway, Denve	r, Colorado 80202		34-7		
4. LOCATION OF WELL (Report location cle See also space 17 below.) At surface	arly and in accordance with any	State requirements.*	10. FIELD AND POOL, OF Basti	C WILDCAT	
660' FSL & 1980' FEL	of Sec. 7, T25N,		11. SEC., T., R., M., OR B	LK. AND	
R11W, NMPM, San Juan	•		Sec. 7, T25N, R11W, NMPM		
14. PERMIT NO.	15. ELEVATIONS (Show whether be	F, RT, GR, etc.)	12. COUNTY OR PARISH	13. STATE	
	6385.5' K	В	San Juan	N.M.	
16. Check App	propriate Box To Indicate N	Nature of Notice, Report, or C	Other Data		
NOTICE OF INTENT	ION TO:	pasaus	ENT REPORT OF:		
FRACTURE TREAT	CLL OR ALTER CASING ULTIPLE COMPLETE X	WATER SHUT-OFF FRACTURE TREATMENT SHOOTING OR ACIDIZING	REPAIRING W ALTERING CA ABANDONMEN	SING	

See attached abandonment prognosis



S. I hereby certify that the pregoing is true and correct	TITLE Division Operations Engr.	DATE _	JUN 2 2 1977
(This space for Federal or State office use)			
APPROVED BY CONDITIONS OF APPROVAL, IF ANY:	TITLE	DATE _	
CC: NIMOCC			

*See Instructions on Reverse Side

⁽Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

24" 85%"

Plug and Abandonment Carson Unit 34-7 Section 7,T 25N, R II W San Juan County, New Mexico

Pertinent Data

Elevation: 6385.5 KB

KB - GL = 16'

Permanent Datum = KB

Past and current status: Presently TiAid.

Has only 7' of ML pay in the GD sand.

Initial prod: Pumped 180 BDO.

Proposed Work: Plug and Abandon

- 1. Pull equipment. If tubing is openended, lower to PBTD, load hole with mud. (Add 20 sax aquagel + 1 sack Benes per 100 bbls of mud or 20 sax salt gel per 100 bbls mud).
- 2. Spot $\underline{20}$ sax Class "G" cement mixed w/l# flocele/sack over perforations and above perforations. Minimum requirements 100' cement plug above perforations. $\omega.o.c.$ 12 hvs.
- 3. Pull tubing.
- 4. Rig up casing pullers. Determine casing free point.
- 6. If casing is recoverable, place cement plugs by cementing through casing or running tubing inside of csg. as it is pulled. Spot Class "G" cement plugs as follows:
 - a. 150' plug across stub of 4½" casing. (50' in casing, 100' in open hole)
 - b. 200' plug from top of Fruitland Coal at 1216' to 1410'.
 - c. 150' plug across base of Ojo Alamo sand at _______. (100' below base of sand and 50' above base of sand).
 - d. 100' plug across shoe of 8-5/8" casing (30' in casing, 70' in open hole).
 - e. 10 sack plug at surface.

4943'
4962'
4981'
4993'
5002'
5014'
5020'
5030'

7. Install permanent abandonment marker as follows:

Steel marker at least 4 inches in diameter set in concrete and extending at least 4' above mean ground level. The name and number of the well and its location (Unit letter, section, township and range) shall be welded, stamped, or otherwise permanently engraved into the metal marker.

- (Continuation from Step 5)
 8. Perforate 4/2 " casing w/4 JSPF as follows:
 - a. Fruitland Coal Pictures Clifs interval 1230' to 1231'. Below Ojo Alamo sand from 470' to 471'.
- 9. Run tubing, spot a 50 sack Class "G" cement plug from 1230 to 590'.
- Pull tubing to ± 400 ', close bradenhead, displace 20 sax through perforations 2 hours.
- Pull tubing to perforations 471 to 471' 11.
- Load $\frac{4/2}{2}$ "casing with cement ($\frac{1}{20}$ sax) and pull tubing. With bradenhead open, displace 20 sax cement through perforations $\frac{470}{20}$ to 471'.
- 13. Spot 10 sack plug at surface.
- 14. Install abandonment marker as outlined in step 7.

260 COC:maf

J. A. Stanzione