

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

~~NM-036254~~ S F 078056

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
Hixon Development Company

3. ADDRESS OF OPERATOR
P.O. Box 2810, Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' FSL, 1980' FWL, Section 6, T25N, R12W

14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.)
6200' GLE

7. UNIT AGREEMENT NAME

Central Bisti Unit

8. FARM OR LEASE NAME

9. WELL NO.

WI-11

10. FIELD AND POOL, OR WILDCAT

Bisti Lower Gallup

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Section 6, T25N, R12W

12. COUNTY OR PARISH 13. STATE

San Juan

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other) Convert well to production

XX

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*


(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is planned to convert this water injection well to production as follows:

- 1) Clean out wellbore to PBD
- 2) Acidize well with 1000 gallons 15% acid
- 3) Put well on pump with rods and insert pump
- 4) Test and evaluate



18. I hereby certify that the foregoing is true and correct

SIGNED

Charles E. Hixon

TITLE

Petroleum Engineer

DATE 12-19-80

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

DATE

RECEIVED

JAN 5 1981

James F. Sims
JAMES F. SIMS

DISTRICT OIL & GAS SUPERVISOR

*See Instructions on Reverse Side