

CP

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir,
Use "APPLICATION FOR PERMIT--" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well <input type="checkbox"/> Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other	8. Well Name and No. Ka Da Pah #2
2. Name of Operator Central Resources, Inc.	9. API Well No. 30-045-22708
3. Address and Telephone No. P.O. Box 2810, Farmington, New Mexico 87499 (505) 326-3325	10. Field and Pool, or Exploratory Area Farmington Bisti
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 1850' FSL, 790' FWL, Section 4, T25N, R12W	11. County or Parish, State San Juan, New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA	
TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input checked="" type="checkbox"/> Other Revised
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water


(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

See attached procedure for proposed plugging operation.

RECEIVED
OCT 21 1998
OIL CON. DIV.
DIST. 3

OCT 15 1998
11:12:19

14. I hereby certify that the foregoing is true and correct			
Signed		Title	District Manager
Thomas DeLong		Date	10/14/98
(This space for Federal or State office use)			
Approved by	/s/ Duane W. Spencer	Title	
Conditions of approval, if any:		Date	OCT 16 1998

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any manner within its jurisdiction.

*See Instruction on Reverse Side

NMOCD

Plugging and Abandonment Procedure
Ka Da Pah #2
Attachment "A"

WELL DATA:

Location: 1850' FSL, 790' FWL, Section 4, T25N, R12W
San Juan County, New Mexico

TD: 1270'
PBTD: 1210'

Surface Casing: 5 1/2", 15.5 ppf, J-55 set @ 44'. Cement w/ 7 sks cement.

Production Casing: 2 7/8", 6.5 ppf, J-55, set @ 1240'. Cement with 75 sks cement.

Perforations: 1063-67', 1080-86', 1140-46' 2 JSPF

PROCEDURE:

1. Pull and lay down 1 1/4" tubing.
2. Mix and pump 29 sacks (34.2 cuft) cement down casing. Displace with water to 300'. Shut down and wait on cement.
3. Rig up wireline services and tag cement. Perforate squeeze holes at 105'.
4. Establish circulation down casing, through perforations at 105', up annulus and out bradenhead.
5. Mix and pump 15 sacks (17.7 cuft) cement down casing through perforations, up annulus and out bradenhead. Leave casing and annulus full of cement.
6. Cut off casing and install regulation dry hole marker. Reclaim location per BLM regulations.