## UNITED STATES DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY

PULL OR ALTER CASING

MULTIPLE COMPLETE

FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL

Free <b>9-3</b> 31	Form Approve  Brager burea (V. 4 -814.7)		
UNITED STATES	E LEAGE		
DEPARTMENT OF THE INTERIOR	t.a12 <u>0-55-3</u>		
GEOLOGICAL SURVEY	6. IF INDIAN ALLOTTEE OR TRIBE NAME		
SUNDRY NOTICES AND REPORTS ON WELLS  (Do not use this form for proposals to drill or to deepen or plug back to a different	Navajo Allotted 7. UNIT AGREEMENT NAME		
reservoir. Use Form 9–331–C for such proposals.)	8. FARM OR LEASE NAME		
1. oil gas other	A.P. Hixon 9. WELL NO.		
2. NAME OF OPERATOR	1		
Hixon Development Company	10. FIELD OR WILDCAT NAME		
3 ADDRESS OF OPERATOR	Bisti Lower Gallup		
P.O. Box 2810, Farmington, NM 87499  4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17	11. SEC., T., R., M OR BLK. AND SURVEY OR AREA		
below.) AT SURFACE: 1850' FNL, 880' FWL 21-25-11	Section 21, T25N, R11W 12. COUNTY OR PARISH 13. STATE		
AT TOP PROD. INTERVAL: AT TOTAL DEPTH:	San Juan NM 14. API NO.		
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE,			
REPORT, OR OTHER DATA	15. ELEVATIONS (SHOW DF, KDB, AND WD)		
CURRENT DEPONIE TO CURRENT DEPONT OF	6517' KB .		
REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:  TEST WATER SHUT-OFF  FRACTURE TREAT  THE STATE OF THE STATE O	EIVED TORRES		

(NOTE: Report results of multiple completion or zone

change on Form 9-330.) - 0 1 5 1000

DORLO O UN ESCLU ON LA MICRI PARMENCATA PERSUURUE AREA CHANGE ZONES ABANDON\* (other) Isolate Cliffhouse and Fruitland Coal/Pictured Cliffs sand with contains

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

> Locate top of primary cement job with a cement bond log. If cement top is above 1668' shut down. If cement top is below 1668' set CIBP inside cemented pipe above Lower Gallup perfs. Perforate 4 holes at 1700'. Pump 50 sacks Class B cement behind pipe from 1700' to 1350'. WOC. Drill out cement and CIBP and hang well on pump.

Subsurface Safety Valve: Manu. and Ty	p <b>e</b>		Set @	Ft.
18. Thereby certify that the foregoing i				
	(This space for Federal or Stat			
APPROVED BYCONDITIONS OF APPROVAL, IF ANY:	TITLE	DATE	APPROV	

\*See Instructions on Reverse Side

Asst AREA MANAGER