Form 9-331 Dec. 1973

> well

below.)

AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE,

Form Approved. Budget Bureau No. 42-R1424

New Mexico

3-3

है जिस्*त* 

12. COUNTY OR PARISH 13. STATE

5 4 É

Rio Arriba

14. API NO.

## UNITED STATES 5. LEASE DEPARTMENT OF THE INTERIOR SF 079403 **GEOLOGICAL SURVEY** 6. IF INDIAN, ALLOTTEE OR TRIBE NAME 7. UNIT AGREEMENT NAME SUNDRY NOTICES AND REPORTS ON WELLS ... San Juan 27-5 Unit (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9–331–C for such proposals.) 8. FARM OR LEASE NAME San Juan 27-5 Unit gas X other 9. WELL NO. 2. NAME OF OPERATOR 95 El Paso Natural Gas Company 10. FIELD OR WILDCAT NAME -3. ADDRESS OF OPERATOR Tapacito Pictured Cliffs 11. SEC., T., R., M., OR BLK. AND SURVEY OR P. O. Box 289, Farmington, N.M. 87401 4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 Section 15, T-27-N, R-5-W AT SURFACE: 500'S & 100'W AT TOP PROD. INTERVAL:

DEDOOT OF OTHER S			· I——							
REPORT, OR OTHER D	DATA			15. ELEVAT				, AND		
REQUEST FOR APPROVAL	TO:	SUBSEQUEN	IT REPORT OF:	<u>6610'</u>	GL	6620 DF		<u> </u>	, 	
TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE			RECEN			Substitution of the control of the c	<u> </u>		· · · · · · · · · · · · · · · · · · ·	
REPAIR WELL PULL OR ALTER CASING			RPD (	(NOTE: Rep	ontresu	ılts of multipl Form 9–330.)	e comp	letion or	zone	
MULTIPLE COMPLETE CHANGE ZONES ABANDON*			U. S. GLULDERO. FARMINGTO!	AL SULVEY						
(other)	FFI	L i	Prittinita				Ŧ		=	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\* 

Request approval to plug and abandon the subject well under the following procedure: కైర్స్ - కో

Unseat packer & T.O.O.H. w/100 jts 1-1/4" N.U. tubing. TI.H. w/112 jts. 1-1/4" tubing and spot a 27 sx cement plug from 3529' to 2714'. Flush tubing w/6.5 barrels 9 lb gel. T.O.O.H. w/ 30 jts tbg. allow cement to set T.I.H. to tag cement top. T.O.O.H. w/ work string perforate 2-7/8" casing w/ squeeze holes @ 172'. Fill hole w/ 9 lb gel. Pump down surface casing w/ 44 sx cement & circulate to surface through 2-7/8" casing to cover inside and outside of 2-7/8" casing from 172' to surface. Cut off surface pipe and casing, erect surface marker, rig down and move off.

The above work to be performed pending partnership approval.

Subsurface Safety Valve: Manu. and Type			<u>3 9 9 8 9 7 9 7 9 7 9 9 9 9 9 9 9 9 9 9 9</u>
18. I hereby certify that the foregoing is t	Fraircor	DATE	Apr <del>il 5</del> , 1982
	(This space for Federal or State office use)	-	APPROVED
APPROVED BY	NMOCC NMOCC	DATE	APR 91987
			Sa SHO DISTART ENGINEER