

A-PLUS WELL SERVICE, INC.

P.O. BOX 1979

Farmington, New Mexico 87499

505-325-2627 * fax: 505-325-1211

Conoco Inc.

June 18, 2001

San Juan 28-7 #34

Page 2 of 2

1650' FNL & 990' FEL, Section 1, T-27-N, R-7-W

Rio Arriba County, NM

Lease No. SF-079321A

API No. 30-039-7192

Plug & Abandonment Report

Plugging Summary Continued:

- 05-16** Held JSA. Open up well. TIH and tag cement at 2532', cement fell back below Fruitland top. Plug #2b with 20 sxs cement inside casing from 2532' to 2432' to cover Fruitland top. PUH to 2190'. Pug #3 with 68 sxs cement with 2% CaCl_2 from 2190' to 1837', increased cement volume due to casing leak, to cover the Ojo Alamo top. PUH to 1840' and WOC. TIH with tubing and tag cement at 1904' (light). Reverse circulate hole clean with 20 bbls water, circulate out 1 to 2 bbls green cement out. R. Snow approved 1904' as TOC. TOH with tubing. RU wireline and round-trip 7" gauge ring to 790'. Perforate 3 HSC squeeze holes at 776'. Set 7" PlugWell wireline retainer at 707'. TIH with tubing and sting into retainer. Load casing with 3 bbls water. Establish rate below CR at 1-1/2 bpm at 300# with circulation out bradenhead and casing vales. Shut in casing valve. Plug #4 with retainer at 707', mix 59 sxs cement, squeeze 26 sxs outside casing from 776' to 676' and leave 33 sxs inside casing to cover Nacimiento top. TOH with tubing. Perforate 3 HSC squeeze holes at 225'. TIH with tubing to 317'. Establish circulation out bradenhead with casing shut in with 12 bbls water at 1-1/2 bpm at 350#. Pug #5 with 104 sxs cement pumped down the tubing to fill the 7" casing and bradenhead from 317' to surface, circulate good cement out casing and out the bradenhead. TOH and LD tubing. SI well and WOC. SDFD.
- 05-17** Held JSA. Open up well. TIH and tag cement in 7" casing at 74'. Load casing with 3 bbls water and pressure test to 500#, held OK. Plug #5b with 20 sxs cement inside 7" casing from 74' to surface, circulate good cement out casing valve. TOH and LD tubing. ND BOP. Dig out wellhead. R. Bishop issued Hot Work permit. Cut off wellhead. Found cement at surface in 7" casing and down 35' in annulus. Mix 10 sxs cement to fill annulus and to install P&A marker. Rig down rig and equipment. Road rig and equipment to A-Plus yard.
R. Snow with BLM, was on location and approved all procedure changes.