UNITED STATES

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

			5.	Lease Number	
Type of Well GAS			6.	NMSF-080669 If Indian, All. or Tribe Name	
Name of Openston		A	7.	Unit Agreement Name	
Name of Operator BURLINGTON	ļ.	LEB STOR			
RESOURCES OIL & GAS COMPANY			8.	San Juan 27-4 Unit Well Name & Number	
Address & Phone No. of Operation PO Box 4289, Farmington, NM		- 97 00 g	<i>y</i> 9.	San Juan 27-4 U #12 API Well No.	
Location of Well, Footage, S	ec., T, R, M		10.	30-039-21022 Field and Pool	
1680'FSL, 1190'FWL, Sec.20,		IPM	11.	Tapacito PC/Blanco County and State Rio Arriba Co, NM	
. CHECK APPROPRIATE BOX TO IN			OTHER	DATA	
Type of Submission X Notice of Intent	Typ:Abandonmen		of Pla		
Subsequent Report	Recompletic Plugging B		nstruc utine	tion Fracturing	
Final Abandonment	Casing Repartment Casing Casin	air Water	Shut o	ff o Injection	
Final Abandonment	_X_ Other - Co		51011 0	o 1111 j 000 2011	
It is intended to comming		ell according to	tho a		
A down hole commin	le the subject w ngle application	will be submitt	ed.	ttached procedure.	
A down hole commin	le the subject w ngle application	will be submitt	ed.	ttached procedure.	
A down hole commin	le the subject w	will be submitt	ed.	ttached procedure.	
A down hole commin	le the subject w	will be submitt	ed.	ttached procedure.	
A down hole commin	le the subject w	will be submitt	ed.	ttached procedure.	
A down hole commin	le the subject w	will be submitt	ed.	ttached procedure.	
A down hole commin	le the subject w	will be submitt	ed.	ttached procedure.	
A down hole commin	le the subject w	will be submitt	ed.	ttached procedure.	
A down hole commin	ngle application	will be submitt	ed.	ttached procedure.	
A down hole comming	e foregoing is tr	will be submitt	ed.	ttached procedure.	
A down hole commin	e foregoing is tr	will be submitt	ed.	Date 2/21/02	

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

SAN JUAN 27-4 UNIT #126 MV/PC 1680' FSL & 1190' FWL Unit L, Sec. 20, T027N, R004W Latitude / Longitude: 36° 33.354' / -107° 16.734'

AIN: 5333701/MV 5333702/PC 2/14/2002 Commingle Procedure

Summary/Recommendation:

SAN JUAN 27-4 UNIT 126 was drilled and completed as a MV/PC dual producer in 1974. In order to optimize production it is recommended to remove the packer, produce both zones up the MV 2-3/8" tubing string. Currently, the Mesaverde is producing 60 MCF/D and production from the Pictured Cliffs is 45 MCF/D. Anticipated uplift is 60 MCF/D from the Mesaverde and 20 MCF/D from the Pictured Cliffs.

NOTE: ALL DEPTHS ARE MEASURED FROM KB. KB to GL was 12'.

- 1. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Cole 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement.
- 2. Broach tbg and set tbg plug in SN at 6077' on the MV string. To ensure the tbg plug is held in place, fill tbg with half of volume with 2% KCL MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. ND WH and NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. (A single-tubing donut and WH for 2-3/8" tubing will be needed.) Test secondary seal and replace/install as necessary.
- 3. Pick up 1-1/4" tubing and RIH to the top of the Model "D" packer (at 3847') and check for fill. If fill is encountered, TOOH w/ 1-1/4" tubing and LD perforated joint. TIH w/ 1-1/4" tubing and circulate any fill off packer. TOOH laying down 1-1/4", 2.3#, K-55 PC tubing (set at 3763').
- 4. Release Baker G-22 seal assembly from the Model D Packer with straight pickup (no rotation required). If seal assembly will not come free, then cut 2-3/8" tubing above the packer and fish with overshot and jars. TOOH and stand back 2-3/8", 4.7#, K-55 Mesaverde tubing set at 6110' (SN @ 6077'). LD seal assembly. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
- PU and TIH with Model CK packer retrieval spear (PRS, with holes drilled near rotary shoe), rotary shoe, drain sub, top bushing, bumper sub, jars, and 4-6 drill collars on 2-3/8", 4.7#, J-55, EUE tubing. Mill out Model D packer at 3847' with air/mist. Note: when using air/mist, the minimum mist rate is 12 bph. After milling over the packer slips, POOH with tools and packer body.
- TIH with 3-7/8" bit and watermelon mill on 2-3/8" tubing. Cleanout to PBTD at +/- 6147' with air/mist. NOTE: When using air/mist, minimum mist rate is 12 bph. If scale is present, contact Operations Engineer and Drilling Superintendent to determine methodology for removing scale from casing and perforations. TOOH w/ tubing.
- 7. TIH with an expendable check on bottom, seating nipple, one joint 2-3/8", 2' x 2-3/8" pup joint, then ½ of the 2-3/8" tubing. Run a broach on sandline to ensure the tubing is clear. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace bad joints as necessary. CO to PBTD with air/mist using a minimum mist rate of 12 bph. Alternate blow and flow periods at PBTD to check water and sand production rates.
- 8. Land tubing at approximately 6110'. ND BOP and NU single-tubing hanger WH. Pump off expendable check. Obtain final pitot gauge up the tubing. Connect to casing and circulate air to assure that the expendable check has pumped off. If well will not flow on its own, make swab run to seating nipple. During cleanout operations the reservoir may be charged with air. As a result of excess oxygen levels that may be in the reservoir and/or wellbore, contact the Lease Operator to discuss the need for determining oxygen levels prior to returning the well to production. RD and MOL. Return well to production.

Area 9

Recommended:

Operations Engineer

Matt Roberts

Office: 599-4098

Cell: 320-2739

Sundry Required: YES

Approved:

Approved:

Rob Gay Lease Operator:

Specialist: Foreman:

Richard Lopez Ward Arnold

Cell: 320-1200

Pager: 326-8837

Cell: 320-6573

Pager: 326-8681

Cell: 320-1689

Pager: 326-8303