Form 9-331

APPROVED BY

CONDITIONS OF APPROVAL

fatisflette In JAMES F. SIMS DISTRICT ENGINEER Form Approved.

Budget Bureau No. 42-R1424 Dec. 1973 UNITED STATES 5. LEASE DEPARTMENT OF THE INTERIOR SF 078060 6. IF INDIAN, ALLOTTEE OR TRIBE NAME **GEOLOGICAL SURVEY** 7. UNIT AGREEMENT NAME SUNDRY NOTICES AND REPORTS ON WELLS Huerfano Unit (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9–331–C for such proposals.) 8. FARM OR LEASE NAME Huerfano Unit gas well X 9. WELL NO. other 51 2. NAME OF OPERATOR 10. FIELD OR WILDCAT NAME El Paso Natural Gas Ballard PC 3. ADDRESS OF OPERATOR 11. SEC., T., R., M., OR BLK. AND SURVEY OR 4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 Sec 21, T-26-N, R-9-W below.) 990'N, 1800'EW 12. COUNTY OR PARISH 13. STATE AT SURFACE: AT TOP PROD. INTERVAL: San Juan AT TOTAL DEPTH: 14. API NO. 16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA 15. ELEVATIONS (SHOW DF, KDB, AND WD) 6391 GL REQUEST FOR APPROVAL TO: SUBSECUENT REPORT OF: TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL Report results of multiple completion or zone change on Form 9-330.) PULL OR ALTER CASING A. CILLALDINAME CONTRACTOR MULTIPLE COMPLETE TARMINGTON, N. W. **CHANGE ZONES** X ABANDON* (other) 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent including estimated date of starting any proposed work. If well is directionally drilled, give subsurface measured and true vertical depths for all markers and zones pertinent to this work.)* 1) Circulate the well with 9 lb/gal mud and spot a plug from COTD to 1945'. Spot a plug from 1749' to 1649' to cover the Fruitland Formation. 2) Spot a plug from 1311' to 1211' to cover the Kirtland Formation. Perforate the 5-1/2" casing at 1045' and squeeze cement behind the casing to 945'. Spot a cement plug from 1045' to 945' inside the casing. Perforate the 5-1/2" casing at 193' and squeeze cement to 93' in the 5-1/2 - 8 5/8 annular space. Spot a plug from 193' to 93' inside the 5-1/2" casing. Cut off the wellhead and cement all casing from 50' to surface. 6) Install dry hole marker. _ Set @ _____ Ft. Subsurface Safety Valve: Manu. and Type _ 18. I hereby certify that the foregoing is true and correct Production July 15, 1982 TITLE Engineer __ DATE .__ SIGNED space for Federal or State office use)

TITLE

__ DATE _