

submitted in lieu of Form 3160-5

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
Sundry Notices and Reports on Wells

1. **Type of Well**  
Gas

2. **Name of Operator**  
Robert L. Bayless

3. **Address & Phone No. of Operator**  
P.O. Box 168, Farmington, NM 87499 (505)326-2659

**Location of Well, Footage, Sec., T, R, M**  
510' FSL 1830' FEL Sec 17, T26N, R18W

5. **Lease Number**  
14-20-603-5035

6. **If Indian, All. or Tribe Name**  
Navajo

7. **Unit Agreement Name**

8. **Well Name & Number**  
Navajo Tribal N #3

9. **API Well No.**  
30-045-05802

10. **Field and Pool**  
Undes. Organ Rock

11. **County & State**  
San Juan County, NM

RECEIVED  
BY JUN 21 1999  
OIL CON. DIV.

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

**Type of Submission**

☐ Notice of Intent

☒ Subsequent Report

☐ Final Abandonment

**Type of Action**

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other -

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut off

☐ Conversion to Injection

13. Describe Proposed or Completed Operations

Robert L. Bayless plugged and abandoned said well on 5-26-99 per attached P&A Report

14. I hereby certify that the foregoing is true and correct.

Signed Tom McCarthy Title Engineer Date 6/14/99

(This space for Federal or State Office use)

APPROVED BY \_\_\_\_\_ Title \_\_\_\_\_ Date \_\_\_\_\_

CONDITION OF APPROVAL, if any:

# A - PLUS WELL SERVICE, INC.

P.O. BOX 1979  
FARMINGTON, NM 87499  
505-325-2627 • FAX: 505-325-1211

Robert L. Bayless

June 9, 1999

## Navajo Tribal "N" #3

510' FSL and 1830' FEL Sec. 17, T-26-N, R-18-W  
San Juan County, NM  
BIA 14-20-603-5035

## Plug & Abandonment Report

### Cementing Summary:

**Plug #1** with retainer at 4304', spot 12 sxs Class B cement above retainer to 3595' to isolate Organ Rock perforations and cover Cutler top.

**Plug #2** with 12 sxs Class B cement inside casing from 3753' to 3595' to cover DeChelly top.

**Plug #3** with 12 sxs Class B cement inside casing from 2840' to 2682' to cover Chinle top.

**Plug #4** with 13 sxs Class B cement inside casing from 2082' to 1911' to cover Entrada and Todiltols tops.

**Plug #5** with 12 sxs Class B cement inside casing from 1514' to 1356' to cover 8-5/8" casing shoe.

**Plug #6** with 14 sxs Class B cement inside casing from 820' to 636' to cover Dakota top.

**Plug #7** with 59 sxs Class B cement from 143' to surface, circulate good cement returns out 8-5/8" casing.

### Plugging Summary:

Notified BLM on 5/24/99

5-24-99 Safety Meeting. Road rig to location, RU. Open up well, no pressure. Layout relief line to pit; casing flowing 1/8" water stream. ND wellhead and NU BOP, test. RU tubing equipment; rusted bolts and jam nuts on wellhead. TOH with 143 joints 2-3/8" tubing, total 4529'. Tubing looks good. TIH with tubing and 4-1/2" DHS cement retainer to 4300'. Shut in well and SDFD.

5-25-99 Safety Meeting. Continue to TIH with retainer; stack out at 4537'. S. Mason, BLM approved procedure change to not spot Hermosa plug. TOH to 4304' and set retainer. Pressure test tubing to 1000#, held OK. Sting out of retainer and load casing; pressure test to 500# for 5 min, held OK. Plug #1 with retainer at 4304', spot 12 sxs Class B cement above retainer to 3595' to isolate Organ Rock perforations and cover Cutler top. TOH to 3753'. Plug #2 with 12 sxs Class B cement inside casing from 3753' to 3595' to cover DeChelly top. TOH to 2840'. Plug #3 with 12 sxs Class B cement inside casing from 2840' to 2682' to cover Chinle top. TOH to 2082'. Plug #4 with 13 sxs Class B cement inside casing from 2082' to 1911' to cover Entrada and Todiltols tops. TOH to 1514' and wait on weather; lightning and hail. Plug #5 with 12 sxs Class B cement inside casing from 1514' to 1356' to cover 8-5/8" casing shoe. TOH to 820'. Plug #6 with 14 sxs Class B cement inside casing from 820' to 636' to cover Dakota top. TOH and LD tubing. Shut in well and start digging out wellhead. SDFD.

5-26-99 Safety Meeting. RU A-Plus wireline truck. TIH and perforate 2 HSC squeeze holes at 143'. Load casing and establish circulation out 8-5/8" casing with 17 bbls water. Plug #7 with 59 sxs Class B cement from 143' to surface, circulate good cement returns out 8-5/8" casing. Shut in well with 200# and WOC. Dig out wellhead and open up well. ND BOP and cut wellhead off; found cement down in casing and annulus. Mix 91 sxs Class B cement, fill casing and annulus; install P&A marker. RD rig and equipment; move off location. J. Ruybalid, BLM, and J. Bennett, Navajo Nation, were on location.