

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	State <input type="checkbox"/> Federal <input type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Ka-Des-Pah
3. Address of Operator PO Box 990, Farmington, New Mexico 87401	9. Well No. 1 (P&A)
4. Location of Well UNIT LETTER K, 1528 FEET FROM THE South LINE AND 1906 FEET FROM THE West LINE, SECTION 18 TOWNSHIP 26N RANGE 8W NMPM.	10. Field and Pool, or Wildcat Ballard Pictured Cliffs
15. Elevation (Show whether DF, RT, GR, etc.) 6205'GL	12. County San Juan

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-commercial production it is planned to plug and abandon this well in the following manner:

Squeeze a 30 sack cement plug below the packer which is set at 1892' to plug the open hole. Spot a 10 sack cement plug on top of packer.

Perofrate squeeze holes in 5 1/2" casing at 1245' (base of Ojo Alamo). Spot a 50 sack cement plug at 1245' and pressure displace 25 sacks through the perofrations to cover the Ojo Alamo outside the casing and leave 25 sacks inside the casing to cover the Ojo Alamo.

Pump 75 sacks cement down the bradenhead. Remove wellhead and spot a 10 sack cement plug at the surface with a plug and abandon marker. Clean up location.

No 5 1/2" casing to be recovered.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed F. H. WOOD

SIGNED _____ TITLE Petroleum Engineer

DATE October 14, 1971

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE 10-18-71

