

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well gas ☒ well other ☐
2. NAME OF OPERATOR
Tenneco Oil Company
3. ADDRESS OF OPERATOR
720 S. Colo. Blvd., Denver, CO 80222
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
1650' FSL, 1650' FEL, Unit K
AT SURFACE: **FWL**
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

- TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☒
(other)

SUBSEQUENT REPORT OF:

- ☐
☐
☐
☐
☐
☐
☐
☐
☐

5. LEASE
SF-079679
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
Delhi-Taylor
9. WELL NO.
6
10. FIELD OR WILDCAT NAME
Basin Dakota
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 17; T26N; R11W
12. COUNTY OR PARISH
San Juan
13. STATE
New Mexico
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
6163' KB

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

2/25/80

We request permission to plug and abandon the Delhi-Taylor #6 by using the procedure detailed on the attached form.



Subsurface Safety Valve: Manu. and Type

18. I hereby certify that the foregoing is true and correct


SIGNED [Signature] TITLE Admin. Supervisor DATE 2/26/80

(This space for Federal or State office use)

APPROVED BY [Signature] TITLE DATE
CONDITIONS OF APPROVAL, IF ANY:

PLUGGING
OPERATIONS AUTHORIZED ARE
SUBJECT TO COMPLIANCE WITH ATTACHED
"GENERAL REQUIREMENTS"

*See Instructions on Reverse Side



NMOC

LEASE Delhi Taylor
WELL NO. 6

9-5/8 "OD, 36 LB, J-55 CSG. W/ 150 CX

TOC @ Surface

170'

5-1/2 "OD, 15.5 LB, J-55 CSG. W/ 250 SX

TOC @ -

DETAILED PROCEDURE

1. MIRUSU. Remove wellhead. Install BOP.
2. POOH w/tbg.
3. RIH w/tbg & Model K cement retainer.
4. Set retainer @5900'.
5. Squeeze Dakota perms w/75 sx neat G cement.
6. POOH w/tbg.
7. Find freepoint, shoot-off & POOH w/csg.
8. RIH w/tbg.
9. Set the following neat G cement plugs while POOH:

Formation	Depth	Size Plug (sx)
Gallup	5200-5240'	25
Bottom Mesa Verde	4100'	50
Top Mesa Verde	2250'	50
PC	1690-1370'	150
Farmington	690-890	100
Csg stub	?	50
Surface	500	200

10. Cut off csg & ~~install PSA marker~~ *4 1/2' below ground level and backfill,*
11. Clean, grade & reseed location.

5990

6015

6190'