UNITED STATES SUBMIT IN TRIPLICATE® DEPARTMENT OF THE INTERIOR (Other Instructions on reverse side)

	_SF_078944
SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
OIL GAS WELL OTHER	7. UNIT AGREEMENT NAME
WELL WELL OTHER 2. NAME OF OPERATOR	8. FARM OR LEASE NAME
Bedford, Inc.	
3. ADDRESS OF OPERATOR	Sullivan =
P.O. Box E - Farmington, New Mexico	15
i. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.)	10. FIELD AND POOL, OR WILDCAT
At surface	Gallegos Gallup
1980' fsl 659' fee Sec 9, T26N, R12W	11. SEC., T., E., M., OR BLK. AND SURVEY OR AREA
San Juan County, New Mexico	Sec 9 T26N R12W
14. PERMIT NO. 15. ELEVATIONS (Show whether DE RT GR etc.)	NMPM
	12. COUNTY OR PARISH 13. STATE
6061 DF	San Juan NM
6. Check Appropriate Box To Indicate Nature of Notice, Report, or	r Other Data
, variation of the state of the	SEQUENT REPORT OF:
TEST WATER SHUT-OFF PULL OR ALTER CASING X WATER SHUT-OFF	
FRACTURE TREAT PULL OR ALTER CASING WATER SHUT-OFF FRACTURE TREATMENT FRACTURE TREATMENT	REPAIRING WELL ALTERING CASING
8HOOT OR ACIDIZE ABANDON* X SHOOTING OR ACIDIZING	ABANDON MENT®
REPAIR WELL CHANGE PLANS (Other)	
	ults of multiple completion on Well
Completion or Reco	ton including actions and district and at a second
17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent details, an	tes, including estimated date of starting any releal depths for all markers and sones perti-
1. Squeeze Gallup Perfs 4977 to 5116 w/50 sx 2. Cut and pull 5 1/2" casing from approx. 1300' 3. Place 150 ft. plug inside and out of stub 4. If casing is recovered below Picture Cliff Place 150 ft plug from 750 to 600 @ base of O	tes, including estimated date of starting any releal depths for all markers and sones perti-
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dai proposed work. If well is directionally drilled, give subsurface locations and measured and true ver nent to this work.)* It is intended to plug and abandon this well in the foll 1. Squeeze Gallup Perfs 4977 to 5116 w/50 sx 2. Cut and pull 5 1/2" casing from approx. 1300' 3. Place 150 ft. plug inside and out of stub 4. If casing is recovered below Picture Cliff Place 150 ft plug over Pictured Cliff 5. Place 150 ft plug from 750 to 600 @ base of O 6. Erect P&A marker w/10 sx surface plug 7. Clean location	tes, including estimated date of starting any releal depths for all markers and sones perti-
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dai proposed work. If well is directionally drilled, give subsurface locations and measured and true ver nent to this work.) 1. Squeeze Gallup Perfs 4977 to 5116 w/50 sx 2. Cut and pull 5 1/2" casing from approx. 1300' 3. Place 150 ft. plug inside and out of stub 4. If casing is recovered below Picture Cliff Place 150 ft plug over Pictured Cliff 5. Place 150 ft plug from 750 to 600 @ base of O 6. Erect P&A marker w/10 sx surface plug	tes, including estimated date of starting any releal depths for all markers and sones perti-
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dai proposed work. If well is directionally drilled, give subsurface locations and measured and true ver nent to this work.)* It is intended to plug and abandon this well in the foll 1. Squeeze Gallup Perfs 4977 to 5116 w/50 sx 2. Cut and pull 5 1/2" casing from approx. 1300' 3. Place 150 ft. plug inside and out of stub 4. If casing is recovered below Picture Cliff Place 150 ft plug over Pictured Cliff 5. Place 150 ft plug from 750 to 600 @ base of O 6. Erect P&A marker w/10 sx surface plug 7. Clean location	tes, including estimated date of starting any releal depths for all markers and sones perti-
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dai proposed work. If well is directionally drilled, give subsurface locations and measured and true ver nent to this work.)* It is intended to plug and abandon this well in the foll 1. Squeeze Gallup Perfs 4977 to 5116 w/50 sx 2. Cut and pull 5 1/2" casing from approx. 1300' 3. Place 150 ft. plug inside and out of stub 4. If casing is recovered below Picture Cliff Place 150 ft plug over Pictured Cliff 5. Place 150 ft plug from 750 to 600 @ base of O 6. Erect P&A marker w/10 sx surface plug 7. Clean location	tes, including estimated date of starting any releal depths for all markers and sones perti-
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dai proposed work. If well is directionally drilled, give subsurface locations and measured and true ver nent to this work.)* It is intended to plug and abandon this well in the foll 1. Squeeze Gallup Perfs 4977 to 5116 w/50 sx 2. Cut and pull 5 1/2" casing from approx. 1300' 3. Place 150 ft. plug inside and out of stub 4. If casing is recovered below Picture Cliff Place 150 ft plug over Pictured Cliff 5. Place 150 ft plug from 750 to 600 @ base of O 6. Erect P&A marker w/10 sx surface plug 7. Clean location	tes, including estimated date of starting any rical depths for all markers and sones perti- lowing manner:
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dai proposed work. If well is directionally drilled, give subsurface locations and measured and true ver nent to this work.)* It is intended to plug and abandon this well in the foll 1. Squeeze Gallup Perfs 4977 to 5116 w/50 sx 2. Cut and pull 5 1/2" casing from approx. 1300' 3. Place 150 ft. plug inside and out of stub 4. If casing is recovered below Picture Cliff Place 150 ft plug over Pictured Cliff 5. Place 150 ft plug from 750 to 600 @ base of O 6. Erect P&A marker w/10 sx surface plug 7. Clean location	tes, including estimated date of starting any releal depths for all markers and sones perti- lowing manner: pipo Alamo APR 1 1 1372
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dai proposed work. If well is directionally drilled, give subsurface locations and measured and true ver nent to this work.)* It is intended to plug and abandon this well in the foll 1. Squeeze Gallup Perfs 4977 to 5116 w/50 sx 2. Cut and pull 5 1/2" casing from approx. 1300' 3. Place 150 ft. plug inside and out of stub 4. If casing is recovered below Picture Cliff Place 150 ft plug over Pictured Cliff 5. Place 150 ft plug from 750 to 600 @ base of O 6. Erect P&A marker w/10 sx surface plug 7. Clean location	tes, including estimated date of starting any rical depths for all markers and sones perti- lowing manner:
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dai proposed work. If well is directionally drilled, give subsurface locations and measured and true ver nent to this work.)* It is intended to plug and abandon this well in the foll 1. Squeeze Gallup Perfs 4977 to 5116 w/50 sx 2. Cut and pull 5 1/2" casing from approx. 1300' 3. Place 150 ft. plug inside and out of stub 4. If casing is recovered below Picture Cliff Place 150 ft plug over Pictured Cliff 5. Place 150 ft plug from 750 to 600 @ base of O 6. Erect P&A marker w/10 sx surface plug 7. Clean location	tes, including estimated date of starting any releal depths for all markers and sones perti- lowing manner: pipo Alamo APR 1 1 1372
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent day proposed work. If well is directionally drilled, give subsurface locations and measured and true ver nent to this work.)* It is intended to plug and abandon this well in the following of the following and pull 5 1/2" casing from approx. 1300' 3. Place 150 ft. plug inside and out of stub 4. If casing is recovered below Picture Cliff Place 150 ft plug over Pictured Cliff 5. Place 150 ft plug from 750 to 600 @ base of O G. Erect P&A marker w/10 sx surface plug 7. Clean location This well is not capable of producing oil or gas economic and give pertinent day proposed work. If well is not capable of producing oil or gas economic and give pertinent day proposed work. If well is not capable of producing oil or gas economic and give pertinent day proposed work. If well is not capable of producing oil or gas economic and give pertinent day proposed work. If well is not capable of producing oil or gas economic and give pertinent day proposed work. If well is directionally dilled, give subsurface locations and give pertinent day of give pert	tes, including estimated date of starting any releal depths for all markers and sones perti- lowing manner: Ojo Alamo APR 1 1 1972
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dail proposed work. If well is directionally drilled, give subsurface locations and measured and true ver nent to this work.)* It is intended to plug and abandon this well in the foll 1. Squeeze Gallup Perfs 4977 to 5116 w/50 sx 2. Cut and pull 5 1/2" casing from approx. 1300' 3. Place 150 ft. plug inside and out of stub 4. If casing is recovered below Picture Cliff Place 150 ft plug over Pictured Cliff 5. Place 150 ft plug from 750 to 600 @ base of O 6. Erect P&A marker w/10 sx surface plug 7. Clean location	tes, including estimated date of starting any releal depths for all markers and sones perti- lowing manner: Ojo Alamo APR 1 1 1972
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent day proposed work. If well is directionally drilled, give subsurface locations and measured and true ver nent to this work.)* It is intended to plug and abandon this well in the following the f	tes, including estimated date of starting any rical depths for all markers and sones perti- lowing manner: Ojo Alamo Omically. APR 1 1 1972 U. S. CYCLOCHE SHOWN.