

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator <b>El Paso Natural Gas Company</b> 3. Address of Operator <b>Box 990, Farmington, New Mexico</b> 4. Location of Well UNIT LETTER <b>M</b> <b>990</b> FEET FROM THE <b>South</b> LINE AND <b>990</b> FEET FROM THE <b>West</b> LINE, SECTION <b>5</b> TOWNSHIP <b>26N</b> RANGE <b>10W</b> NMPM.	7. Unit Agreement Name <b>Huerfano Unit</b> 8. Farm or Lease Name <b>Huerfano Unit</b> 9. Well No. <b>14</b> 10. Field and Pool, or Wildcat <b>E. Kutz Pictured Cliffs</b> 11. Elevation (Show whether DF, RT, GR, etc.) <b>6591' DF</b> 12. County <b>San Juan</b>
---	--

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-commercial production it is intended to plug and abandon this well in the following manner:

Spot a 35 sack cement plug down tubing to cover from 2215' across the 5 1/2" casing shoe.

Determine the free point of the 5 1/2" casing, shoot off at free point, spot a 25 sack cement plug on the casing & stub, pull casing.


If there is not enough 5 1/2" casing free to make recovery economical, the casing will be shot off and no plug will be spotted.

~~XXXX~~ Place a 10 sack cement plug and a 4" x 4' plug and abandonment marker in the top of the surface casing.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by  
Carl E. Matthews

SIGNED \_\_\_\_\_ TITLE **Petroleum Engineer**



DATE **9-12-67**

APPROVED BY Emory Edwards  
CONDITIONS OF APPROVAL, IF ANY:

TITLE Sup Dist III

DATE 9-13-67