

NO. OF COPIES RECEIVED	5
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	3

5-000
1-F

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
☒ ~~XXXXXX~~ Federal ~~XXXXXX~~
5. State Oil & Gas Lease No.
~~XXX~~ SF-078899

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator Beta Development Co. 3. Address of Operator 125 Petr. Club Plaza, Farmington, New Mexico 4. Location of Well UNIT LETTER J, 1680 FEET FROM THE South LINE AND 1480 FEET FROM THE East LINE, SECTION 5 TOWNSHIP 26N RANGE 11W NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) 6234.4 G.R.	7. Unit Agreement Name 8. Farm or Lease Name Man Federal 9. Well No. 1 10. Field and Pool, or Wildcat Basin Dakota 12. County San Juan
---	--

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to repair casing leak as follows:

Rig up work over unit, circulate all mud and shale out of well w/fresh water 1% Calcium Chloride, CO to T.D. Pull 1-1/2" tbg out of well, GIH w/3-7/8" bit on 2-7/8" tbg., ream out any tight places in csg. CO to T.D. Circulate hole clean. POH and run packer on 2-7/8" tbg. w/2-seal assembly w/perforated nipple in between seals, bull plug on bottom w/stop ring. Set packer, pull tbg up until stop ring catches at bottom of packer. This will have bottom seal assembly inside of Model "P" packer. Pump in cement, displace w/water, over-flush w/2 bbls., slack tbg off until top assembly sets down on packer. Swab well in.

Release rig. After well has cleaned up, re-acidize w/500 gals. 15% reg. mud acid.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>D. E. Bayless</u>	TITLE <u>Superintendent</u>	DATE <u>4-1-68</u>
APPROVED BY <u>Curry</u>	TITLE <u>Sup Dist IV</u>	DATE <u>4-2-68</u>
CONDITIONS OF APPROVAL, IF ANY:		