UNITED STATES SUBMIT IN TRIPLICATE® (Other Instructions on reverse side)

Form approved. Budget Bureau No. 42-R1424. 5. LEASE DESIGNATION AND SERIAL NO.

GEOLOGICAL SURVEY

SF-079679

SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)	6. IF INDIAN, ADJUSTED ON THIS NAME
1.	7. UNIT AGREEMENT NAME
OIL S GAS WELL OTHER 2. NAME OF OPERATOR	8. FARM OR LEASE NAME
El Paso Products Company	DElhi Taylor
3. ADDRESS OF OPERATOR	

P. O. Box 1560, Farmington, New Mexico
Location of Well (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

3 10. FIELD AND POOL, OR WILDCAT

Gallegos Gallup 11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

660'N, 1980'E, 26N, 11W

17-26N-11W

15. ELEVATIONS (Show whether DF, RT, GR, etc.) 14. PERMIT NO. 6163'GL

12. COUNTY OR PARISH | 13. STATE San Juan

New Mexico

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF .			
TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACCOIZE REPAIR WELL	PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON* CHANGE PLANS	<u>x</u>	WATER SHUT-OFF FRACTURE TREATMENT SHOOTING OR ACIDIZING (Other) (NOTE: Report results of a completion of the completi	REPAIRING WELL ALTERING CASING ABANDONMENT* multiple completion on Well n Report and Log form.)	_
(Other)			Completion of Recompletion	2 xecpost and _38 zor,	

17. DESCRIBE PROPOSED OF COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

(Est. date to start work 4-1-68

- Load hole with mud laden fluid. 1.
- Squeeze Gallup perforations. 2.
- Shoot pipe loose at free point and pull. 3.
- Spot 100'cement plug 50' in and 50' out of stub. 4.
- Spot 100' cement plug across top of picture cliff. 5.
- Spot 100' cement plug at base of Ojo Alamo. 6.
- Place cement plug in top of surface with welded marker in place. 7.
- Clean location.

MAR 2 9 1968

U. S. GEOLOGICAL SUPV



18. I hereby certif; that the foregoing of true and correct					
		Agent	· · · · · · · · · · · · · · · · · · ·	DATE 3-20-68	
(This space for Federal or State office use)			•		
APPROVED BY	TITLE			DATE	