

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE\*  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424  
5. LEASE DESIGNATION AND SERIAL NO.

NOO-C-19-20-5431

6. IF INDIAN ALLOTTEE OR THE NAME

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

NAVAJO TRIBE

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

NAVAJO TRIBE 'BS'

9. WELL NO.

2

10. FIELD AND POOL, OR WILD AT

TOCITO DOME FIELD

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

M-23-T26N-R18W

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5619' DF

12. COUNTY OR PARISH

SAN JUAN

13. STATE

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

SUBSEQUENT REPORT OF:

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.)\*

Propose to abandon the well as follows: (collapsed at 3100')

1. Pull on rods and tubing.
2. If just rods or neither come, back rods off plunger and proceed to #3. If tubing comes, attempt to repair casing.
3. Cut tubing above collapse and set packer at 3050'.
4. Pump 80 sacks cement thru packer (assume all will cover pay zone and up to the top of the Ismay at 6100').
5. If can't pump 80 sacks down, cut casing above collapse and place 50 sack plug in and out of the casing stub and over collapse zone. Go to #10.
6. If can pump 80 sacks down, assume covered pay zone and pump + 600 ft.<sup>3</sup> of mud thru packer.
7. Pump 50 sacks into collapse area of the Dechelly thru packer.
8. Cut casing above collapse and remove.
9. Place 50 sack plug in and out of the casing stub.
10. Pump + 600 ft.<sup>3</sup> mud in hole and place a 50 sack plug across the bottom of the surface casing at 1570'.
11. Fill the remaining hole with mud.

(CONTINUED)

18. I hereby certify that the foregoing is true and correct

SIGNED

*Alvin R. May*

TITLE

FIELD FOREMAN

DATE

4-20-76

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

\*See Instructions on Reverse Side

