

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Floyd Operating Company

3. Address and Telephone No.

711 Louisiana, Suite 1740, Houston, Texas 77002

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

990' FSL and 990' FWL Sec 33, T26N, R12W

5. Lease Designation and Serial No.

N00-C-14-20-7464

6. If Indian, Allottee or Tribe Name

Navajo Alloted

7. If Unit or CA, Agreement Designation

M

8. Well Name and No.

Navajo "LB" #1

9. API Well No.

30-045-23922

10. Field and Pool, or Exploratory Area

WAW Fruitland Pictured Clif

11. County or Parish, State

San Juan Co., New Mexico

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well Plugged and Abandoned September 13, 1993.

Plugging Summary:

Drive rig and equipment to location. Rig up and spot equipment; lay relief line to pit. Open well up and bleed down. ND wellhead and NU BOP. POH and tally 34 joints 2 - 3/8" tubing, 1107'. RIH with open ended tubing to 1107' and pump 10 bbls water. Plug #1 from 1107' to 528' with 44 sxs Class B cement. Pull out of hole with tubing. RIH and tag cement at 747'. Pressure test casing to 500#, held OK. Procedure change approved by W. Townsend and K. Schneider with BLM; reviewed well information and observed cement in the bradenhead valves. POH to 727'. Plug #2 from 727' to surface with 55 sxs Class B cement, circulate good cement to surface. Pull tubing and LD. Shut in well and dig out casing head. Open well up and ND BOP. Cut off wellhead and fill casing with cement, then install P&A marker; total 20 sxs cement. Cut off anchors below ground level. Rig down and move off location.

Cement Plugs:

Plug #1 - from 1107' to 528' with 44 sxs Class B cement.

Plug #2 - from 727' to surface with 55 sxs Class B cement, circulate good cement to surface

14. I hereby certify that the foregoing is true and correct

Signed

Title Manager of Production

Date

9/22/93

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Approved as to plugging of the well bore.
Liability under bond is retained until
surface restoration is completed.

APPROVED

SEP 29 1993

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side

NMOCD