UNITED STATES

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

Sundry Notices and Repor	ta on Wolla	
Sundry Notices and Repor	is on wells	
	5. Lease SF-07	Number
1. Type of Well GAS	6. If Ir	ndian, All. or
2		Agreement Name
2. Name of Operator BURLINGTON	Huerf	ano Unit
RESOURCES OIL & GAS COMPANY		
	8. Well	Name & Number
3. Address & Phone No. of Operator		ano Unit #262E
PO Box 4289, Farmington, NM 87499 (505)		Vell No. 15-26267
4. Location of Well, Footage, Sec., T, R, M	10. Field	and Pool
1480'FSL 1490'FEL, Sec.31, T-26-N, R-10-W,		Dakota
		y and State Tuan Co, NM
12. CHECK APPROPRIATE BOX TO INDICATE NATURE	OF NOTICE, REPORT, OTHER DATA	
Type of Submission T	ype of Action	
X Notice of Intent Abandonm		
Subsequent Report Plugging		rina
Casing R		
	Casing Conversion to Inje	ction
X Other -		
13. Describe Proposed or Completed Operatio	ıs	
It is intended to repair the tubing on	the subject well aggording to	+ho
attached procedure.	the subject well according to	ciie
-		
		1
		, -1
14. I hereby certify that the foregoing is	crue and correct.	
	Requlatory Administrator Date	
Signed ARA REC (KIM1) Title (This space for Federal or State Office use)	Requlatory Administrator Date	2/9/99 TLW
Signed ARA REC (KIM1) Title (This space for Federal or State Office use)	Requlatory Administrator Date	

Huerfano Unit #262E

Dakota

1480' FSL & 1490' FEL

Unit J, Section 31, T26N, R10W

Latitude / Longitude: 36° 26.4716' / 107° 55.9937'

DPNO: 5396701 Tubing Repair Procedure

Project Summary: The Huerfano Unit #262E was drilled in 1985. The tubing has not been pulled since originally installed. A partial plunger is plugging the tubing. We propose to pull the tubing, check for fill, replace any worn or scaled tubing and add a plunger lift.

- Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental 1. regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required Lefore the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
- MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow 2. well down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
- The Dakota tubing is 2-3/8", 4.7#, J-55 EUE set at 6333'. Release donut, pick up additional 3. joints of tubing and tag bettom (record depth.) PBTD should be at +/- 6407'. TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
- If fill covers any perforations then TIH with 3-7/8" bit and a watermelon mill on 2-3/8" tubing to 4. below perforations, cleaning out with air/mist. PU above the perforations and flow the well naturally, making short trips for clean up when necessary. TOOH with tubing. NOTE: When using air/mist, minimum mist rate is 12 bph.
- TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one 5. joint off bottom. Run a broach on sandline to insure that the tubing is clear. Land tubing at approximately 6330'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. If well will not flow on it's own, make swab run to SN. RD and MOL. Return well to production.

6. Production operations will install the plunger lift.

Recommended:

Operations Engineer

Approved:

Kevin Midkiff

Office - 326-9807

Pager - 564-1653