

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

SF-078079

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR
Bonneville Fuels Corporation

3. ADDRESS OF OPERATOR
1600 Broadway, Suite 1110, Denver, CO 80202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface
800' FSL & 920' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GN, etc.)
6121' GR

7. PERMIT AGREEMENT NAME

8. FARM OR LEASE NAME

Scott 'E' Federal

9. WELL NO.

10. FIELD AND POOL, OR WILDCAT
10

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
W. Kutz-Pictured Cliffs

25P-T27N-R11W

12. COUNTY OR PARISH

San Juan

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

BFC proposes to P&A the subject well as follows:

1. Set cement retainer @ \pm 1680' and squeeze Pictured Cliffs perfs f/1695'-1721' w/100 sx Class B cement. Formation tops: Ojo Alamo-660', Kirtland Sh-815', Fruitland-1515', Pictured Cliffs-1696'. Pull out of Retainer and spot a 50' cement plug on top of Retainer.
 2. Set 50' sx Class B plug from 900-1400'.
 3. Set cement retainer @ \pm 500'. Squeeze w/1200 sx Class B cement.
 4. Set 10' sx surface plug and dry hole marker.
 5. Rehabilitate location and road per BLM specifications.
- Work will commence upon BLM and partner approval and rig availability.

2) Spot a 100' cement Plug (Plus 100% excess) from 1511' to 1411'.

3) Spot a cement plug from 862 to 605' (100% excess)

4a) Perforate at 150' and circulate cement to the surface leaving the 4 1/2" casing full of cement.

Note: 9.0 lb/gal mud is to be placed between plugs.

18. I hereby certify that the foregoing is true and correct

SIGNED G. D. Smiley

TITLE Operations Supervisor

DATE 10/4/90

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

APPROVED
AS AMENDED

OCT 17 1990

AREA MANAGER

*See Instructions on Reverse Side