

**UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY**

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well  gas well  other \_\_\_\_\_

2. NAME OF OPERATOR  
**Beta Development Co.**

3. ADDRESS OF OPERATOR  
**125 Petroleum Plaza, Farmington NM 87401**

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: **NE/4 NW/4 790/N-1850/W**  
AT TOP PROD. INTERVAL: **6550**  
AT TOTAL DEPTH: **6675**

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:	SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF <input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE <input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES <input type="checkbox"/>	<input type="checkbox"/>
ABANDON* <input checked="" type="checkbox"/>	<input type="checkbox"/>
(other) _____	_____

5. LEASE  
**SF-078092**

6. IF INDIAN, ALLOTTEE OR TRIBE NAME \_\_\_\_\_

7. UNIT AGREEMENT NAME \_\_\_\_\_

8. FARM OR LEASE NAME  
**Douthit Federal**

9. WELL NO.  
**1**

10. FIELD OR WILDCAT NAME  
**Basin Dakota**


11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
**Sec. 27 27N-11W NMPM**

12. COUNTY OR PARISH **San Juan** 13. STATE **New Mexico**

14. API NO. \_\_\_\_\_

15. ELEVATIONS (SHOW DF, KDB, AND WD)  
**6370' GR**

(NOTE: Report results of multiple completion or zone change on Form 9-330.)



17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Plug and abandon the above mentioned well in the following manner subject to your approval:

- #1 Pump 50 sacks cement into Dakota perforations 6550-6634
- #2 Pump 25 sacks cement on top of perforations 6550-6273
- #3 Pump 25 sacks cement across 2 stage collar @ 2198-1921 across P. C.
- #4 Shoot and recover any free 4 1/2" casing.
- #5 Pump cement plug 50' in and 150' out of casing stub.
- #6 Pump cement plug from 950'-1150' (base of Ojo-Alamo @ 1015').
- #7 Cut all pipe off 4' below ground level, (Agricultural area) no dry hole marker required
- #8 Pump 10 sacks cement in top of 10 3/4" surface pipe.
- #9 Clean up location and rehabilitate in accordance of B.L.M. instructions.

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED \_\_\_\_\_ TITLE **Superintendent** DATE **5-31-78**

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

*Old*