

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF-04739-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		RECEIVED OCT 22 1974	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Petroleum Corporation of Texas			8. FARM OR LEASE NAME Day
3. ADDRESS OF OPERATOR P. O. Box 911, Breckenridge, Texas			9. WELL NO. 1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 330' FSL and 330' FWL			10. FIELD AND POOL, OR WILDCAT Fulcher-Kutz P.C.
14. PERMIT NO.		15. ELEVATIONS (Show whether DF, RT, GR, etc.)	11. SEC., T., R., M., OR BLE. AND SURVEY OR AREA Sec. 20-T28N-R10W N.M.P.M.
			12. COUNTY OR PARISH San Juan
			13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
(Other) Plug & Abandon	X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
(Other)	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to Plug and Abandon this well in the following manner:

1. Set cement plug from PBTD - 2112' to 50' above 5½" casing shoe at 2003'.
2. A. If cut and pull 5½" casing more than 100' below base of Ojo Alamo:
 1. Set 100' cement plug in and out of casing stub.
 2. Set 100' cement plug at base of Ojo Alamo.
 3. If have water flow, set 100' cement plug at 300'.
- B. If cut and pull 5½" casing above Ojo Alamo.
 1. Perforate casing at base of Ojo Alamo.
 2. Squeeze perforations with sufficient cement to have 100' of cement in annulus and inside casing.
 3. If have water flow set 100' cement plug at 300'.
3. Set 50' cement plug at base of surface casing.
4. Set cement plug in top of surface casing with dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

Ewell N. Walsh, P. E.

TITLE

President, Walsh Engineering
& Production Corp.

DATE Oct. 21, 1974

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side