Form 3160-5 (June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREALL OF LAND MANAGEMENT

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

BOILEAG OF EAT	AD MANAGEMENT	
OUNDRY MOTIOEC AS	UD DEDODTE ON WELLE	5. Lease Designation and Serial No.
SUNDRY NOTICES AND REPORTS ON WELLS		SF-077085
	or to deepen or reentry to a different reservoir.	6. If Indian, Allottee or Tribe Name
Use "APPLICATION FOR	PERMIT - " for such proposals	/
		7 M. Main and C.A. Assessment Designation
		7. If Unit or CA, Agreement Designation
1. Type of Well		
Oil Gas Well Other		8. Well Name and No.
2. Name of Operator	Attention:	Omler A # 14
Amoco Production Company	Lois Raebrun	9. API Well No.
3. Address and Telephone No.		3004525326
P.O. Box 800, Denver, Colorado 80201	(303) 830-5294	10. Field and Pool, or Exploratory Area
	n)	Otero Chacra
4. Location of Well (Footage, Sec., T., R., M., or Survey Descriptio	14	11. County or Parish, State
860 FNL 950 FEL	Sec. 25 T 28N R 10W	
		San Juan New Mexeco
CHECK ADDRODDIATE DOV	(s) TO INDICATE NATURE OF NOT	TICE REPORT OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF A	ACTION
	(52)	
⊠	Abandonment	Change of Plans
Notice of Intent	Recompletion	New Construction
C. S.	Plugging Back	Non-Routine Fracturing
Subsequent Report	Casing Repair	Water Shut-Off
Final Abandonment Notice	Altering Casing Other	Conversion to Injection Dispose Water
		(Note: Report results of multiple completion on Well Completion or
		Recompletion Report and Log form.)
Amoco Production Company request perr Please see attached procedure. If you have questions please contact Car	DECI SEP OIL GO	SIVED WILL ON FARMION WILL ST. S.
14. I hereby certify that the foregoing is true and correct Signed ALL ALL (This space for Federal or State office use)		ness Assistant Date 08-29-1994
Approved by	Title	Date
Approved by Conditions of approval, if any:		ADD

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fict

representations as to any matter within its jurisdiction.

PXA Procedures Omler A #14

- 1. Check location for anchors. Install if necessary. Test anchors.
- 2. MIRUSU. Blow down well. Kill if necessary with fresh water. NDWH. NUBOP.
- 3. POOH with 1 1/4" tbg and lay down. RIH with 2 3/8" tbg and cement retainer, set retainer at 3082'. Test casing integrity to 500#. Squeeze perfs at 3138' to 3150' with 16.878 cuft cement.
- 4. Pull out of retainer and spot cement plug to surface with 413.759 cuft cement.
- 5. NDBOP. Cut off casing and wellhead. Install PXA marker according to BLM or State requirements.
- 6. Turn over to John Schwartz for reclamation.
- 7. Rehabilitate location according to BLM or State requirements.

OMLER A 014

Location - 25A- 28N-10W SINGLE ck Orig.Completion - 6/82 Last File Update - 1/89 by BCB

