

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-10J  
Revised 1-1-89

DISTRICT I  
P.O. Box 1960, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DC, Artesia, NM 88210

DISTRICT III  
1000 Rio Arriba Rd., Las Alamos, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

|                                      |  |
|--------------------------------------|--|
| WELL API NO.                         | 30-045-25997   |
| 5. Indicate Type of Lease            | STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/> |
| 6. State Oil & Gas Lease No.         |  |
| 7. Lease Name or Unit Agreement Name | Sullivan, B.R. True<br>Bruce R.  |
| 8. Well No.                          | #2   |
| 9. Pool name or Wildcat              | Otero Chacra   |

|  |  |
|--|--|
| SUNDRY NOTICES AND REPORTS ON WELLS<br>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)  |  |
| 1. Type of Well:<br>Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other <input type="checkbox"/>  |  |
| 2. Name of Operator<br>Amoco Production Company Attn: John Hampton   |  |
| 3. Address of Operator<br>P.O. Box 800, Denver, Colorado 80201   |  |
| 4. Well Location<br>Unit Letter <u>J</u> : <u>1700</u> Feet From The <u>South</u> Line and <u>1480</u> Feet From The <u>East</u> Line<br>Section <u>23</u> Township <u>28N</u> Range <u>10W</u> <u>14-11-1</u> San Juan County<br>10. Elevation (Show whether OF, R.O.D., AT, GA, etc.)<br><u>5736' GL</u> |  |

|   |   |
|---|---|
| 11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data |   |
| NOTICE OF INTENTION TO:   | SUBSEQUENT REPORT OF:                               |
| PERFORM REMEDIAL WORK <input type="checkbox"/>                                | REMEDIAL WORK <input type="checkbox"/>              |
| TEMPORARILY ABANDON <input type="checkbox"/>                                  | ALTERING CASING <input type="checkbox"/>            |
| PULL OR ALTER CASING <input type="checkbox"/>                                 | COMMENCE DRILLING OPS. <input type="checkbox"/>     |
| OTHER: <u>Bradenhead Repair</u> <input checked="" type="checkbox"/>           | PLUG AND ABANDONMENT <input type="checkbox"/>       |
|   | CASING TEST AND CEMENT JOB <input type="checkbox"/> |
|   | OTHER: <input type="checkbox"/>                     |

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including anticipated date of starting any proposed work) SEE RULE 1103.

Amoco intends to perform the attached workover procedure to eliminate bradenhead pressure.

RECEIVED  
MAY 26 1992  
OIL CON. DIV.  
DIST. 3

Please contact Ed Hadlock (303) 830-4982 if you have any questions.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE J.L. Hampton TITLE Sr. Staff Admin. Supv. DATE 5/20/92  
TYPE ON PRINT NAME John Hampton

(This space for State Use)

Original Signed by CHARLES GHOLSON

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE MAY 26 1992

COPIES OF ORIGINAL, IF ANY:

813329  
NOV 1957  
NOV 1957  
NOV 1957

SULLIVIAN, B R#2  
LOCATION J23 28N 10W  
SINGLE CH  
ORIGINAL COMPLETION 3/85  
LAST FILE UPDATE 1/92 BY CSW

BOT OF 3.625 IN OD CSA 294  
24 LB/FT. K-55 CASING, W/250 SKS  
CIR TO SURFACE  
OJO ALAMO @780  
FRUITLAND @1130  
PICTURED CLIFFS @1810

CH PERF 2808-2828

2914-2932

BOT OF 2.875 IN OD TBG AT 2945

PBTD AT 3050 FT.

TOTAL DEPTH 3100 FT.

BOT OF 4.5 IN OD CSA 3100  
10.5 LB/FT. J-55 CASING  
W/600 SKS  
CIR TO SURFACE

Workover Procedure  
Sullivan, Bruce R. True #2  
Sec.23-T28N-R10W  
San Juan County, NM

1. Contact Federal or State agency prior to starting repair work.
2. Catch gas and/or water sample off of bradenhead and casing, and have analyzed.
3. Install and/or test anchors on location.
4. MIRUSU. Check and record tubing, casing and bradenhead pressures.
5. Blow down well and kill well, if necessary, with 2% KCL water.
6. ND wellhead. NU and pressure test BOP's.
7. TIH and tag PBTD, check for fill. Trip and tally out of hole with tubing, checking condition of tubing.
8. TIH with bit and scraper to top of perforations. A seating nipple and standing valve may be run in order to pressure test tubing. TOH.
9. TIH with RBP and packer. Set RBP 50-100 ft. above perforations. TOH one joint and set packer. Pressure test RBP to 1500 psi.
10. Pressure test casing above packer. Isolate leak, if any, by moving packer up the hole and repeating pressure test.

NOTE: If this can not be accomplished, contact Brent Miller in Denver at (303)830-4049. If no leak is found, it may be necessary to perforate the casing below surface casing depth or above the top of cement in order to circulate cement to surface.

11. Establish injection rate into leak, if found, and attempt to circulate to surface.
12. Release packer, spot sand on RBP and TOH with packer.
13. Run, if necessary, a CBL and CCL to determine cement top.
14. Perforate casing above cement top, if necessary, with 4 JSPF and circulate dye to determine cement volume.

15. Depending on depth of hole and circulating pressure, a packer or cement retainer may be needed.16. Mix and pump sufficient cement (Class B or equivalent, with a setting time of 2 hours) to circulate to surface. Shut bradenhead valve and attempt to walk squeeze to obtain a 1000 psi squeeze pressure. WOC.
17. TIH with bit and scraper and drill out cement. Pressure test casing. TOH with bit and scraper.
18. TIH with retrieving head for RBP. Circulate sand off of RBP and TOH with RBP.
19. TIH with sawtooth collar and/or bailer and clean out hole to PBTD, if fill was found in step 7. TOH.
20. TIH with production string (1/2 mule shoe on bottom and seating nipple one joint off bottom) and land tubing to original depth. NDBOP. NU wellhead.
21. Swab well in and put on production.
22. RDMOSU.