

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well gas ☒ well other ☐
2. NAME OF OPERATOR
Northwest Pipeline Corporation
3. ADDRESS OF OPERATOR
P.O. Box 90, Farmington, N.M. 87499
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 890 FNL & 1700 FEL NW/NE
AT TOP PROD. INTERVAL: 890 FNL & 1700 FEL
AT TOTAL DEPTH: 890 FNL & 1700 FEL
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:
TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☒
(other) ☐

SUBSEQUENT REPORT OF:

☐ RECEIVED
AUG 22 1983
☐ BUREAU OF LAND MANAGEMENT
☐ FARMINGTON RESOURCE AREA
☐

5. LEASE
Tr. #165 Cont. #82
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
Jicarilla Apache
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
Indian E
9. WELL NO.
#1
10. FIELD OR WILDCAT NAME
Choza Mesa Pictured Cliffs
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
NE/4 Sec 31, T29N, R3W
12. COUNTY OR PARISH
Rio Arriba
13. STATE
N.M.
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
7022' GR

(NOTE: Report results of multiple completion or zone change on Form 9-331-C)

OIL CON. DIV.
DIST. 3

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Move in P&A Unit and RU and install BOP
2. Pull 1" tbg
3. Pull 2-3/8" tbg and visually inspect.
4. With wireline shoot four circulation holes at 3360' (Ojo Alamo 3314'-3454')
5. TIH w/ 2-3/8" to bottom of open hole (PBD @ 3905') and spot 100 sx (118 cu.ft) C1 "B" cement to cover open hole and inside 7" casing to 50' above Fruitland. (3572'). TOC @ 3522'.
6. Come up hole w/ 2-3/8" tubing, spot 100 sx (118 cu.ft) cement inside 7" across Ojo Alamo (3314'-3454') and displace into perms to cover Ojo Alamo.
7. TOH w/ 2-3/8" tbg.
8. Recover wellhead.
9. Spot 20 sx (23.6 cu.ft) cement from (0'-50') at surface and install dry hole marker.

10. Clean up location. Recontour and seed location.
Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Mike J. Turnbaugh TITLE Senior Engineer DATE 8-22-83
Mike J. Turnbaugh

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY.

B

MJM/djb/

ok

*See Instructions on Reverse Side

NMOCC

APPROVED

AUG 24 1983
M. Millendach
M. MILLENDACH
AREA MANAGER