

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

nm09979

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Suburban Propane Gas Company

3. ADDRESS OF OPERATOR

P.O. Drawer 1980 Farmington, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

Unit letter N 660 Feet from the South line and 1980 Feet from the west

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6091 GL

7. UNIT AGREEMENT NAME

S. E. Cha Cha

8. FARM OR LEASE NAME

S. E. Cha Cha

9. WELL NO.

29

10. FIELD AND POOL, OR WILDCAT

Gallup

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 15 T-28 North

R-13 West N.M.P.M.

12. COUNTY OR PARISH 13. STATE

San Juan

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☒

(Other)

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐

ALTERING CASING ☐


ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

In order to increase production on the above well, we propose to workover this well as follows:

1. Move in pulling, pull tubing and packer.
2. Set bridge plug at 5710.
3. Run baker packer, and look for holes in casing.
4. After finding hole, squeeze bad casing.
5. Drill out test casing, if okay drill out bridge plug clear out to T.D.
6. Run tubing with packer and acidize perf. swab test.
7. Pull packer, run production tubing, pump and rods, and put back on production.



18. I hereby certify that the foregoing is true and correct

SIGNED

Donald J. Miller

TITLE Superintendent of Rockey-

DATE 8-9-77

(This space for Federal or State office use)

Mountain Area

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

1. 100% PRODUCTION

OK
NEW

*See Instructions on Reverse Side

AUG 10 1977

U.S. GEOLOGICAL