

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well gas ☒ well other ☐
2. NAME OF OPERATOR
Northwest Pipeline Corporation
3. ADDRESS OF OPERATOR
PO Box 90, Farmington, New Mexico 87401
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 1460' FSL & 1460' FWL
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>	<input type="checkbox"/>
(other)		

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is our intent to plug & abandon as follows:

1. Pump 25 sks C1"B" cmt & displace to 7500'.
2. MIRU P & A service unit. Find free point in 2-7/8" using stretch method.
3. Cut off 2-7/8" above free point.
4. Spot 10 sks cmt @ cut off point & @ 4972', if possible (top MV). Pull 2-7/8" pipe.
5. Find free point in 4-1/2" using stretch method.
6. Cut off 4-1/2" above free point.
7. Spot 20 sks cmt @ cut off point & pull 4-1/2" pipe.
8. Find free point in 7" using stretch method.
9. Cut off 7" above free point.
10. Spot 40 sks cmt @ cut off point & pull 7" pipe.
11. Spot 40 sks cmt on 9-5/8" shoe @ 202'.

Subsurface Safety Valve: Manu. and Type

12. Spot 20 sks cmt in surface pipe & install P & A marker. Set @ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED P. M. Pippin TITLE Production Engineer DATE March 30, 1979

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

5. LEASE
NM 03471
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
San Juan 29-6 Unit
8. FARM OR LEASE NAME
San Juan 29-6 Unit
9. WELL NO.
105
10. FIELD OR WILDCAT NAME
Basin Dakota
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec 28 T29N R6W
12. COUNTY OR PARISH
Rio Arriba
13. STATE
New Mexico
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
6349' GR

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

