

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

SF-078281

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Abandonment

2. NAME OF OPERATOR

Northwest Pipeline Corp.

3. ADDRESS OF OPERATOR

P. O. Box 90 Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

1830' FNL & 2210' FEL

7. UNIT AGREEMENT NAME

San Juan 29-5 Unit

8. FARM OR LEASE NAME

San Juan 29-5 Unit

9. WELL NO.

72

10. FIELD AND POOL, OR WILDCAT

Basin Dakota

11. SEC., T., E., M., OR BLE. AND
SURVEY OR AREA

Sec. 17, T29N, R5W NMPM

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

12. COUNTY OR PARISH
Rio Arriba

13. STATE
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☒

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

The well was plugged and abandoned in the following manner:

7-15-75 Ran 2 3/8" tubing & spot 15 sack cement plug from 6397 - 6175. Pick up tubing spot 11 sack cement plug from 6013' to 5895'.

7-17-75 Shot 4.5" casing off @ 3412' & pulled same: Ran 2 3/8" tubing & spot 21 sack cement plug 3550 to 3380'. Pick up tubing & spot 58 sack cement plug from 3000' to 2700'.

7-19-75 Shot 7" casing off @ 1958' & pulled same.

7-21-75 Ran 2 3/8" tubing & spot 18 sack cement plug from 1975 to 1925'. Pick up tubing & spot 18 sack cement plug from 325' to 275'. Spot 11 sack cement plug 30' to 0' in surface. Install 4.5" dry hole marker and release rig.

18. I hereby certify that the foregoing is true and correct

SIGNED

O. B. Whitenburg
O. B. Whitenburg

TITLE

Sr. Prod. & Drlg. Engr.

DATE

8-1-75

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: