

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

1. Type of Well  
GAS

2. Name of Operator

**BURLINGTON  
RESOURCES**

OIL & GAS COMPANY

3. Address & Phone No. of Operator

PO Box 4289, Farmington, NM 87499 (505) 326-9700

4. Location of Well, Footage, Sec., T, R, M

1650' FSL, 990' FWL, Sec. 27, T-29-N, R-7-W, NMPM

5. Lease Number  
SF-078425

6. If Indian, All. or  
Tribe Name

7. Unit Agreement Name  
San Juan 29-7 Unit

8. Well Name & Number  
San Juan 29-7 U #59

9. API Well No.  
30-039-07537

10. Field and Pool  
Blanco Mesaverde

11. County and State  
Rio Arriba Co, NM

RECEIVED  
JUN 19 1998  
OIL CON. DIV.  
DIST. 8

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission

Type of Action

<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input checked="" type="checkbox"/> Other - Tubing Repair	

13. Describe Proposed or Completed Operations

It is intended to repair the tubing on the subject well according to the attached procedure.

RECEIVED  
58 JUN 11 PM 3:29  
OIL CONSERVATION, NMA

14. I hereby certify that the foregoing is true and correct.

Signed [Signature] (LTL8) Title Regulatory Administrator Date 6/5/98  
VKH

(This space for Federal or State Office use)

APPROVED BY /s/ Duane W. Spencer

Title

Date JUN 17 1998

CONDITION OF APPROVAL, if any:

**San Juan 29-7 Unit #59**  
**Blanco Mesaverde**  
**Unit L, Sec. 27, T-29-N, R-7-W**  
**Latitude / Longitude: 36° 41.64462' / 107° 33.80586'**  
**Recommended Tubing Repair Procedure 5/5/98**

**NOTE: ALL DEPTHS ARE MEASURED FROM KB. KB to GL was 12'.**

1. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Prior to moving in rig, make one-call and then verify rig anchors and dig pit.
2. MIRU workover rig. NU relief line and blow well down (kill with 2% KCL water only if necessary). ND WH and NU BOP. Test and record operation of BOP rams. Replace any WH valves that do not operate properly. Test secondary seal and install or replace if necessary.
3. **Mesaverde, 2-3/8", 4.7#, J-55 tubing set at 5934' (188 jts).** Broach tubing and set tubing plug in nipple at **5904'**. Fill tubing with half of its volume of 2% KCL to insure the tubing plug will be held in place. Release donut, pick up additional joints of tubing and tag bottom, recording the depth. PBTD should be at +/- **5984'**. TOOH and stand back 2-3/8" tubing. Visually inspect tubing for corrosion, and replace any bad joints. Check tubing for scale and notify Operations Engineer if it is present.
4. TOL 2, 3480 TIH with 4-3/4" bit, bit sub, and watermelon mill on 2-3/8" tubing and round trip to PBTD, cleaning out with air/mist. **NOTE: When using air/mist, mist rate must not be less than 12 bph.** Speak with Operations Engineer, and if necessary, determine the best way to remove scale from the casing and perforations.
5. TIH with one joint of 2-3/8" tubing with expendable check, F-nipple (one joint off bottom), then 1/2 of the 2-3/8" production tubing. Run a broach on sandline to insure that the tubing is clear. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace any bad joints. CO to PBTD with air/mist.
6. PU above the top Mesaverde perforation at **5353'** and flow the well naturally, making short trips for clean-up when necessary. Obtain pitot gauge from casing and report this gauge after final clean-up.
7. Land tubing at **5885'**. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. If well will not flow on its own, make swab run to SN. RD and MOL. Return well to production.

Recommended: *Tom Loveland* Operations Engineer **5/18/98** Approved: *Bruce D. Briggs* **6-1-98**  
Drilling Superintendent

**Contact:**

L. Tom Loveland

Office 326-9771  
Pager 324-2568  
Home 564-4418