State of New Mexico Energy, Minerals and Natural Resources Department Oil Conservation Division

Sundry Notices and Re	ports on Wells
	API # (assigned by OCD)
	30-039-07590
1. Type of Well	5. Lease Number
GAS	Fee 6. State Oil&Gas Lease #
	6. State Oil&Gas Lease #
2. Name of Operator	7. Lease Name/Unit Name
BURLINGTON RESOURCES OTL 5 CAS COMPANY	
RESOURCES OIL & GAS COMPANY	San Juan 29-7 Unit
	8. Well No. 71
3. Address & Phone No. of Operator PO Box 4289, Farmington, NM 87499 (505) 326-9700	9. Pool Name or Wildcat
PO BOX 4289, Farmington, NM 8/499 (305) 326-9700	Blanco Mesaverde
4. Location of Well, Footage, Sec., T, R, M	10. Elevation:
1080'FNL 800'FEL, Sec.24, T-29-N, R-7-W, NMPM, Rio A	rriba County
Type of Submission Type of Act	ion
X Notice of Intent Abandonment	_ Change of Plans
Recompletion	
	Non-Routine Fracturing
	Water Shut off
Final Abandonment Altering Casing X_ Other -	_ Conversion to Injection
13. Describe Proposed or Completed Operations It is intended to run a spinner survey on the subto the attached procedure.	oject well according
-	
ការ	CHIVEN
$\Pi \Pi^{-}$	NOV 1 7 1998
വിത	CON. DIV.
	DIST. 3
SIGNATURE SIGNATURE SIGNATURE SIGNATURE Regulatory Admir	nistratorNovember 16, 1998
('	TLW
(This space for State Use)	
OFPIITY OU # /	GAS INSPECTOR, DIST. #3 NOV 1 7 1000
ADIONAL GIGLER BY CHADLES 7 DEDOM	GAS INSPECTOR, DIST. #3 NOV 1 7 1998
Approved by Title	

San Juan 29-7 Unit #71

Blanco Mesaverde Unit A, Section 24, T29N, R07W Rio Arriba County, New Mexico Elevation 6251' GL, 6262' KB LAT: 36.715729' Long: 107.515579'

Summary:

The San Juan 29-7 Unit #71 was spudded in April of 1959 and was originally completed in the Point Lookout, and the Cliffhouse. In September of 1995, the Lewis and Menefee were added and the Cliffhouse was restimulated. By running the spinner flowmeter, the percent contribution of the Lewis and of the individual zones within the Lewis can be determined. The data gathered in this sweep of spinner surveys will be combined with the spinner data gathered in the spring of 1998 to help determine the ideal stimulation design for the Lewis Shale.

Procedure:

1. Comply with all NMOCD, BLM, and BR regulations. Conduct daily safety meetings for all personnel on location.

DO NOT KILL WELL. ANY FLUIDS USED IN WELLBORE WILL INVALIDATE DATA NEEDED. IF FLUIDS ARE REQUIRED, CONTACT MICHELE QUISEL OR STEVE CAMPBELL TO DISCUSS ALTERNATIVES.

- 2. Inspect location and wellhead and install rig anchors prior to rig move if needed.
- 3. MOL, hold safety meeting and RU slickline unit. SI Master valve. ND bullplug on flowtee. RU full lubricator and test to 1500 psi. Open master valve. RIH w/slickline and set tubing choke in FN @ 5359 ' (1.78" I.D. bore). RD slickline unit. SI master valve.
- 4. RU workover unit. Check all safety equipment to insure proper location and working order. ND wellhead and NU 7-1/16" 3000 BOP, spool, stripping head and blooie line to pit. Continue to flow well through casing valve. Flow well through casing valve and blow well through blooie line to pit.
- 5. Strip174 jts. 2-3/8" 4.7# J-55 tubing through stripping head and stand back. ND stripping head. SI rams on BOP.

THE WELL WILL REMAIN ON PRODUCTION DURING THE ENTIRE SPINNER SURVEY.

San Juan 29-7 Unit #71

Blanco Mesaverde Unit A, Section 24, T29N, R07W Rio Arriba County, New Mexico Elevation 6251' GL, 6262' KB LAT: 36.715729' Long: 107.515579'

- **6.** RU Schlumberger. RU full lubricator and test to 1500 psi. Open rams on BOP and RIH w/ spinner flowmeter tool/GR/CCL. Correlate depth to GR/CCL logs provided by the engineer on location.
- 7. Take spinner survey readings at the following stations:

•	Station #1	3902'	Top of Navajo City Chacra
	Station #2	4098'	Top of Otero Chacra
•	Station #3	4230'	Top of Middle Bench of Otero Chacra
•	Station #4	4653'	Top of Upper Cliff House
	Station #5	4850'	Top of Massive Cliff House

- **8.** Tag bottom w/ spinner tool. POOH w/ spinner flowmeter tool/GR/CCL and SI rams on BOP. RD full lubricator. RD and release Schlumberger..
- 9A. If fill, TIH w/ 4-3/4" bit and CO to PBTD. TOOH.
- 9. NU stripping head. Open rams on BOP. Strip 174 jts. 2-3/8" 4.7# J-55 tubing w/ expendable check and seating nipple one joint off bottom and land tubing @ 5391'. Pump off expendable check. ND stripping head, BOP, spool, and blooie line. NU wellhead. RD and release rig.
- 10. NU bullplug and flowtee. Open master valve and put well on production.