

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company		8. Farm or Lease Name Hardie A
3. Address of Operator Box 990, Farmington, New Mexico - 87401		9. Well No. 2
4. Location of Well UNIT LETTER M , 990 FEET FROM THE South LINE AND 990 FEET FROM THE West LINE, SECTION 24 TOWNSHIP 29N RANGE 8W NMPM.		10. Field and Pool, or Wildcat Blanco Mesa Verde
15. Elevation (Show whether DF, RT, GR, etc.) 6352' GL		12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

On 8-18-69 set a cement retainer at 4437', squeezed the uncemented liner and producing zones w/400 sacks of cement.

Three attempts to mill a window in the 7" casing through which a deviated hole could be drilled failed.

Due to excessive workover cost it is planned to plug and abandon this well and drill a new well.

The Ojo Alamo was adequately covered from contamination during the primary cement job.

Put a 10 sack cement plug at base of Ojo Alamo inside casing.

Determine free point of 7" casing by stretch. Shoot casing off above free point and spot a 50 sack cement plug by displacing cement down the casing.

Pull 7" casing. Place a 25 sack cement plug across base of surface casing.

Place a 15 sack cement plug at surface, install a dry hole marker and clean the location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Certified Signed By:

SIGNED Donald R. Read

TITLE Petroleum Engineer

DATE 10-13-69

APPROVED BY [Signature]

TITLE Sup Dist III

DATE 10-14-69

CONDITIONS OF APPROVAL, IF ANY:

