

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

- | | |
|--|--|
| <p>1. Type of Well
GAS</p> <p>2. Name of Operator
BURLINGTON
RESOURCES
OIL & GAS COMPANY</p> <p>3. Address & Phone No. of Operator
PO Box 4289, Farmington, NM 87499 (505) 326-9700</p> <p>4. Location of Well, Footage, Sec., T, R, M
884' FSL, 1065' FWL, Sec.12, T-29-N, R-8-W, NMPM</p> | <p>5. Lease Number
SF-078502A</p> <p>6. If Indian, All. or
Tribe Name</p> <p>7. Unit Agreement Name</p> <p>8. Well Name & Number
Vandewart #1</p> <p>9. API Well No.
30-045-08438</p> <p>10. Field and Pool
Blanco Mesaverde</p> <p>11. County and State
San Juan Co, NM</p> |
|--|--|

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission

Type of Action

- | | | |
|--|---|--|
| <input checked="" type="checkbox"/> Notice of Intent | <input type="checkbox"/> Abandonment | <input type="checkbox"/> Change of Plans |
| <input type="checkbox"/> Subsequent Report | <input type="checkbox"/> Recompletion | <input type="checkbox"/> New Construction |
| <input type="checkbox"/> Final Abandonment | <input type="checkbox"/> Plugging Back | <input type="checkbox"/> Non-Routine Fracturing |
| | <input type="checkbox"/> Casing Repair | <input type="checkbox"/> Water Shut off |
| | <input type="checkbox"/> Altering Casing | <input type="checkbox"/> Conversion to Injection |
| | <input checked="" type="checkbox"/> Other - Tubing repair | |

13. Describe Proposed or Completed Operations

It is intended to repair the tubing in the subject well according to the attached procedure.

RECEIVED
JUN 8 1998

OIL CON. DIV.
DIST. 3

070 FARMINGTON, NM
JUN 27 11:00

14. I hereby certify that the foregoing is true and correct.

Signed Nancy Oltmanns (KLM6) Title for Regulatory Administrator Date 5/26/98

(This space for Federal or State Office use)

APPROVED BY By Deane W. Spencer Title _____ Date JUN 11 1998

CONDITION OF APPROVAL, if any:

^D
Vanewart #1
Mesa Verde
884' FSL, 1065' FWL
Unit M, Section 12, T-29-N, R-08-W
Latitude / Longitude: 36° 44.0927' / 107° 37.9441'
DPNO: 47989A
Tubing Repair Procedure

Project Summary: The Vandewart No. 1 is a Mesa Verde producer drilled in 1951 and sidetracked in 1968. The well has not been pulled since 1968. This well produces 311 MCFD with a compressor. We propose to check for fill and repair any worn or scaled tubing (due to it's age).

1. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. **Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.**
2. MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
3. The Mesa Verde tubing is 2-3/8", 4.7#, J-55 tubing is set at 5203'. Release donut, pick up additional joints of tubing and tag bottom. (Record depth.) PBTB should be at +/- 5461'. TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
4. If fill covers any perforations, then TIH with 3-7/8" bit and a watermelon mill on 2-3/8" tubing to below perforations, cleaning out with air/mist. **NOTE: When using air/mist, minimum mist rate is 12 bph.**
5. PU above the perforations and flow the well naturally, making short trips for clean up when necessary. TOOH with 2-3/8" tubing. TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom. Run a broach on sandline to insure that the tubing is clear.
6. Land tubing at 5340'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. Obtain pitot gauge up the tubing. If well will not flow on it's own, make swab run to SN. RD and MOL. Return well to production.

Recommended: Kevin Midkiff 5/19/08
Operations Engineer

Approved: Bruce D. Bony 5-21-08
Drilling Superintendent

Kevin Midkiff
Office - 599-9807
Pager - 564-1653