UNITED STATES

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

Sundry Not.	ices and Reports on Wells	es en en en en	
		5.	Lease Number SF-078415-A
1. Type of Well GAS	A 10.2027		If Indian, All. or Tribe Name
	1AN 2000	7.	Unit Agreement Name
2. Name of Operator BURLINGTON RESOURCES	& GAS COMPANY OF CAST 9	627.28	
	<u> </u>	8.	Well Name & Number
3. Address & Phone No. of Opera PO Box 4289, Farmington, NM 87		9.	Day #2A API Well No. 30-045-21779
4. Location of Well, Footage, S 1130'FNL, 950'FWL, Sec.9, T-			Field and Pool Blanco PC/Blanco M
		11.	County and State San Juan Co, NM
12. CHECK APPROPRIATE BOX TO IN	DICATE NATURE OF NOTICE, RE	PORT, OTHER	DATA
Type of Submission	Type of Action		
X Notice of Intent		hange of Pla	
Subsequent Report	Recompletion N Plugging Back N	ew Construc	
Subsequent Report		ater Shut o	
Final Abandonment	Altering Casing C		
	X Other - Commingle		
13. Describe Proposed or Comp	leted Operations	<u> </u>	
		ng to the a	ttached procedure
It is intended to comming	le the subject well accordi	ng to the a	ctached procedure.
14. I hereby certify that the	e foregoing is true and corr	rect.	
signed Jagay Cale	Title Regulatory Admin	<u>istrator</u> Dat	e 12/20/99
(This space for Federal or State APPROVED BY	te Office use) Title Active Faurt		1/13/00
ch fe			

DAY #2A

Blanco Pictured Cliffs/Blanco Mesaverde AIN: 4820301/ 4820302 1130' FNL & 950' FWL Unit D, Sec. 09, T29N, R08W

Latitude / Longitude: 36° 44.6219'/ 107° 41.1081'
Recommended Commingle Procedure

Project Summary:

The Day #2A was drilled in 1976 and completed in the Mesaverde formation. In 1985, the Pictured Cliffs zone was added. Current Pictured Cliffs production is 27 MCF/D and 218 MCF/D from the Mesaverde. It is proposed to pull both tubing strings and clean-out to PBTD. The well will then be commingled with a single 2-3/8" tubing string and a plunger lift. Anticipated uplift is estimated at 100 MCF/D.

Commingle Procedure:

- 1. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Cole 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
- 2. MOL and RU workover rig. Conduct safety meeting for all personnel on location. NU relief line. Blow down well and kill with 2% KCL water as necessary. ND wellhead and NU BOP. Test and record operation of BOP rams. Have wellhead and valves serviced at machine shop to convert to a single string wellhead (2-3/8"). Test secondary seal and replace/install as necessary.
- 3. TOOH laying down the 1-1/4", Pictured Cliffs tubing (set at 3193') with orange peeled joint on bottom.
- 4. Release Model G-22 (Assumed) seal assembly from the Model F Packer with straight pickup (no rotation required). If seal assembly will not come free, then cut 2-3/8" Mesaverde tubing above the packer and fish with overshot and jars. TOOH with 2-3/8" 4.7#, J-55, Mesaverde tubing (set at 5688') and Model G-22 seal assembly. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
- 5. TIH with Model HE packer retrieval spear (PRS, with holes drilled near rotary shoe), rotary shoe, drain sub, top bushing, bumper sub, jars, and 4-6 drill collars on 2-3/8". Mill out Model F packer at 3222' with air/mist. Note: when using air/mist, the minimum mist rate is 12 bph. Try to maintain air rate at 1,400 cfm. A hydrocarbon stable foamer should be utilized since this well makes significant amounts of condensate. After milling over the packer slips, POOH with tools and packer body.
- 6. PBTD should be at 5728'. TIH with 3-7/8" bit, bit sub and watermelon mill on 2-3/8" tubing and cleanout to PBTD with air/mist. Note: When using air/mist, minimum mist rate is 12 bph. TOOH with tubing.
- 7. TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom. Broach all tubing and land at approximately 5688'. ND BOP and NU single string wellhead (2-1/16" master valve). Pump off expendable check and blow well in. Return well to production.

8. Production Operations will install the plunger lift.

Recommended: Mile

Operations Engineer

Approval:

Bruce W. Bown 12-9-99
Drilling Superintendent

Operations Engineer

Mike Haddenham

Office - 326-9577

Pager - 327-8427

Mdh/amm 12/03/99