

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

RECEIVED
JAN 31 PM 1:17

OTO WELLS, NM

1. Type of Well
GAS

5. Lease Number
SF 078414 A
6. If Indian, All. or
Tribe Name

2. Name of Operator
**BURLINGTON
RESOURCES**

7. Unit Agreement Name

3. Address & Phone No. of Operator
PO Box 4289, Farmington, NM 87499 (505) 326-9700

8. Well Name & Number
Day #1A

9. API Well No.
30-045-22711

4. Location of Well, Footage, Sec., T, R, M
1750' FNL, 1500' FWL, Sec. 17, T-29-N, R-8-W

10. Field and Pool
Blanco MV

11. County and State
San Juan Co., NM

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission

Type of Action

<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input checked="" type="checkbox"/> Other -tubing repair	

13. Describe Proposed or Completed Operations

It is intended to repair tubing on the subject well according to the attached procedure.

RECEIVED
JAN 13 1998
OIL CON. DIV.
DIST. 3

14. I hereby certify that the foregoing is true and correct.

Signed Duane W. Spencer (MEL6) Title Regulatory Admin. Date 12/30/97

(This space for Federal or State Office use)

APPROVED BY Duane W. Spencer Title _____ Date JAN - 9 1998

CONDITION OF APPROVAL, if any:

NMOCD

Day #1A
Mesaverde
1750'N 1500'W
Unit F, Section 17, T-29-N, R-08-W
Latitude / Longitude: 36° 43.64' / 107° 42.08'
DPNO: 47950A
Tubing Repair Procedure

1. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. **Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS.** Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
2. MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
3. Release donut, pick up additional joints of tubing and tag bottom. (Record depth.) TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
4. If casing requires clean out, TIH with bit and bit sub and CO to PBTD prior to running casing scraper. Roundtrip casing scraper and bit to below perforations. (Do not clean out with casing scraper.) PU above perforations and flow the well naturally, making short trips for clean up when necessary. TOOH.
5. TIH with 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom. Rabbit all tubing. CO to PBTD.
6. Land tubing near 5560'. ND BOP and NU wellhead. Pump off expendable check. Obtain final pitot gauge up the tubing. If well will not flow on it's own, make swab run to seating nipple. If a swab run is not necessary, run a broach on slickline to ensure that the tubing is clear. RD and MOL. Return well to production.

Recommended: MEL Lutey
Operations Engineer

Approved: _____
Drilling Superintendent

Mary Ellen Lutey
Office - (599-4052)
Home - (325-9387)
Pager - (324-2671)

MEL/mel