Form 3160-5 (August 1999)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

VDRY	NOTICES	REPORTS	ON WELLS	

SUN

FORM APPROVED
OMP NO. 1004-0135
Expires: November 30, 2000

5. Lease Serial No. NMSF078132

abandoned well. Use form 3160-3 (APD) for such proposals. SUBMIT IN TRIPLICATE - Other instructions on reverse side.					If Indian, Allottee or Tribe Name 7. If Unit or CA/Agreement, Name and/or No.				
									Type of Well
Name of Operator BP AMERICA PRODUCTION	CO Contact:	MARY CORLE E-Mail: corleyml(9. API Well No. 30-045-08585-00-C1				
3a. Address P. O. BOX 3092 HOUSTON, TX 77253		3b. Phone No. (Ph: 281.366. Fx: 281.366.0	include area code 4491)700		10. Field and BALLARI BASIN	Pool, or E	xploratory		
4. Location of Well (Footage, Sec., T	., R., M., or Survey Description)			11. County or Parish, and State				
Sec 11 T29N R9W NWNW 1085FNL 1010FWL 36.74324 N Lat, 107.75334 W Lon					SAN JUAN COUNTY, NM				
12. CHECK APPE	ROPRIATE BOX(ES) TO	INDICATE N	NATURE OF	NOTICE, RE	PORT, OR	OTHER	DATA		
TYPE OF SUBMISSION	TYPE OF ACTION								
Notice of Intent	☐ Acidize	□ Deepe	☐ Deepen		☐ Production (Start/Resume)		☐ Water Shut-Off		
Notice of Intent	☐ Alter Casing	☐ Fractu	re Treat	□ Reclamat	tion		☐ Well Integrity		
☐ Subsequent Report	□ Casing Repair	☐ New (Construction	☐ Recompl	ete		☐ Other		
☐ Final Abandonment Notice	☐ Change Plans	🛮 Plug a	nd Abandon	□ Tempora	☐ Temporarily Abandon				
	☐ Convert to Injection ☐ P		Back	☐ Water Disposal					
If the proposal is to deepen directions Attach the Bond under which the wo following completion of the involved testing has been completed. Final At determined that the site is ready for f BP America respectfully reque Plug and Abandonment Proce	rk will be performed or provide operations. If the operation resoundonment Notices shall be file inal inspection.) est permission to plug and	the Bond No. on faults in a multiple ed only after all re	file with BLM/BI completion or recountries and the completion or recountries and the complete th	A. Required sub completion in a no iding reclamation	sequent reports ew interval, a F , have been cor	shall be f form 3160	iled within 30 days -4 shall be filed once		
14. I hereby certify that the foregoing is	s true and correct. Electronic Submission # For BP AMERICA committed to AFMSS for pro	N PRODUCTION	CO, sent to the	ne Farmington					
Name (Printed/Typed) MARY CO	RLEY		Title AUTHO	ORIZED REPI	RESENTATI	VE			
Signature (Electronic S	Submission)		Date 08/23 /2	2002					
	THIS SPACE FO	R FEDERAL	OR STATE	OFFICE US	E		,		
A. CTERLET	LMACON		Title DCT	BOLEUM EN	CINEED	Date 09	3/26/2002		
	MASON		Title PET	ROLEUM EN	CHINELY I	Date VC			
Conditions of approval, if any, are attached certify that the applicant holds legal or equivalent would entitle the applicant to cond	uitable title to those rights in the	e subject lease	Office Farn	nington					

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.


A.L. Elliott A #2 P&A Procedure

Procedure:

- 1. Check anchors. MIRU workover rig.
- 2. Check and record tubing, casing, and bradenhead pressures.
- 3. Blow down wellhead. Kill with water if necessary.
- 4. Nipple down WH. NU BOPs.
- 5. PU 1-1/4" workstring.
- 6. RIH with 2-7/8" cement retainer. Set retainer at 2550'. TIH with 1-1/4" workstring and sting into cement retainer. Squeeze Fruitland Coal and Picture Cliffs perforations with 50 cu ft cement. PU and spot 100'cement plug (3.5 cu ft) above retainer from 2450'-2550'. TOH.
- 7. RU WL unit. RIH and perforate squeeze holes thru 2-7/8" and 4-1/2" casing at 1800".
- 8. RIH with 2-7/8" cement retainer. Set retainer at 1750". TIH with 1-1/4" workstring and sting into cement retainer. Squeeze Ojo Alamo with 65 cu ft cement. PU and spot 100 cement plug (35 cu ft) above retainer from 1650'-1750". TOH.
- 9. RU WL unit. RIH and perforate squeeze holes thru 2-7/8" and 4-1/2" casing at 250'.
- 10. Pump 125 cu ft cement down casing and circulate to surface. Leave casing full of cement.
- 11. ND BOP's. Cut off wellhead and install P&A marker.

AL Elliott A#2

Sec 11, T29N, R9W API#30045-08585



NOTES

1) Ran & comented 2-7/8" casing above perfs in 1982 due to severe casing leaks

updated: 1/31/02 jad