

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL/API NO. 30-045-24817
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. Property Code: 003200
7. Lease Name or Unit Agreement Name Jasis Canyon
8. Well No.
9. Pool name or Wildcat Blanco Pictured Cliffs
10. Elevation (Show whether DF, RKB, RT, GR, etc.) GR 6254'

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER
2. Name of Operator Conoco, Inc.
3. Address of Operator 10 Desta Dr. Ste 100W, Midland, TX 79705

4. Well Location Unit Letter H : 1030/660 North Line and 1185/1170 East Line Section: 28/36 Township 30S Range 8E NMPM San Juan County
--

10. Elevation (Show whether DF, RKB, RT, GR, etc.) GR 6254'
--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug and abandon this well according to the attached procedure and wellbore diagrams.

RECEIVED
JUL 24 1995

OIL CON. DIV.
DIST. 3

I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
SIGNATURE <u>Jerry W. Hoover</u>	Sr. Conservation Coordinator DATE 7/19/95
TYPE OR PRINT NAME <u>Jerry W. Hoover</u>	(915) 686-6548 TELEPHONE NO.

(This space for State Use)	
APPROVED BY <u>Johnny Robinson</u>	DEPUTY OIL & GAS INSPECTOR, DIST. #3 DATE JUL 24 1995
CONDITIONS OF APPROVAL, IF ANY:	

PLUG & ABANDONMENT PROCEDURE

5-10-95

Jasis Canyon #1
Blanco Pictured Cliffs
NE Section 36, T-29-N, R-8-W
San Juan County, New Mexico

Note: All cement volumes use 100% excess outside pipe and 50' excess inside pipe. The stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures.

1. Install and test location rig anchors. Prepare blow pit. Comply to all NMOCD, BLM, and Conoco safety regulations.
2. MOL and RU daylight pulling unit. Conduct safety meeting for all personnel on location. NU relief line. Blow down well and kill with water as necessary. ND wellhead and NU BOP. Test BOP.
3. POH and tally 1-1/4" tubing (2386'). Visually inspect, if necessary LD and PU 2" tubing workstring.
4. Plug #1 (Pictured Cliffs perforations and Fruitland top, 2986' - 2552'): RIH with open ended tubing to 2986' or as deep as possible. Pump 15 bbls water down tubing. Mix 49 sxs Class B cement (50% excess, long plug), and set a balanced plug from 2986' to 2552' to cover Pictured Cliffs perforations and Fruitland top. POH and WOC.
5. RIH and tag cement. Load casing and circulate clean. Pressure test casing to 500#. POH to 2150'.
6. Plug #2 (Kirtland and Ojo Alamo tops, 2150' - 1910'): Mix 22 sxs Class B cement and set a balanced plug inside casing to cover Kirtland and Ojo Alamo formation tops from 2150' to 1910'. POH with tubing.
6. Plug #3 (Nacimiento, 830' - 730'): Perforate 4 squeeze holes at 830'. Establish rate into squeeze holes if casing tested. PU 4-1/2" cement retainer and RIH; set at 780'. Pressure test tubing to 1000#, establish rate into Nacimiento squeeze holes. Mix 51 sxs Class B cement and squeeze 39 sxs cement outside 4-1/2" casing from 1450' to 1350' and leave 12 sxs cement inside casing to cover Nacimiento top. POH and LD tubing and setting tool.
7. Plug #4 (Surface): Perforate 2 squeeze holes at 248'. Establish circulation out bradenhead valve. Mix and pump approximately 71 sxs Class B cement from 248' to surface, circulate good cement out bradenhead valve. Shut in well and WOC.
8. ND BOP and cut off wellhead below surface casing. Install P&A marker with cement to comply with regulations. RD, MOL, cut off anchors, and restore location.

Jasis Canyon #1

Current

Blanco Pictured Cliffs

NE Section 36, T-29-N, R-8-W, San Juan County, NM

Today's Date: 5/10/95

Spud: 10/31/81

Completed: 12/16/81

12-1/4" Hole

8-5/8" 24# K-55 Csg set @ 198'
Cmt w/200 sxs (Circulated to Surface)

Nacimiento @ 780'

Top of Cmt @ 1840' (CBL)

Ojo Alamo @ 1960'

Kirtland @ 2100'

Fruitland @ 2602'

1-1/4" 2.4# Tubing @ 2886'

Pictured Cliffs @ 2905'

Pictured Cliffs Perforations:
2916' - 2936'

PBTD 3078'

7-7/8" Hole

4-1/2" 10.5# K-55 set @ 3078'
Cmt w/ 352 sxs cmt

TD 3150'

Jasis Canyon #1

Proposed P & A
Blanco Pictured Cliffs

NE Section 36, T-29-N, R-8-W, San Juan County, NM

Today's Date: 5/10/95
Spud: 10/31/81
Completed: 12/16/81

