

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

1. Type of Well
GAS

2. Name of Operator
BURLINGTON RESOURCES OIL & GAS COMPANY

3. Address & Phone No. of Operator
PO Box 4289, Farmington, NM 87499 (505) 326-9700

4. Location of Well, Footage, Sec., T, R, M
990' FSL, 1650' FWL, Sec. 35, T-30-N, R-6-W, NMPM

5. Lease Number
NM-04139

6. If Indian, All. or Tribe Name

7. Unit Agreement Name
San Juan 30-6 Unit

8. Well Name & Number
San Juan 30-6 Unit #5

9. API Well No.
30-039-07716

10. Field and Pool
Blanco Mesaverde

11. County and State
Rio Arriba Co, NM

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA ~~REPORT~~ NATURE

Type of Submission

Type of Action

<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input checked="" type="checkbox"/> Other - Tubing Repair	

13. Describe Proposed or Completed Operations

It is intended to repair the tubing in the subject well according to the attached procedure.

14. I hereby certify that the foregoing is true and correct.

Signed *Sandy Cole* Title Regulatory Administrator Date 12/20/99
trc

(This space for Federal or State Office use)

APPROVED BY *Chip Hamadon* Title Acting Team Leader Date 1/18/00
CONDITION OF APPROVAL, if any:

San Juan 30-6 Unit #5
Blanco Mesaverde DPNO: 6972801
990' FSL, 1650' FWL
Unit N, Section 35, T-30-N, R-06-W
Latitude: 36° 45.8661', Longitude: 107° 26.1145'


Summary/Recommendation:

The San Juan 30-6 Unit #5 was suspended in 1953, then completed open-hole in the Mesaverde formation. In 1970, the openhole was cement squeezed, then sidetracked and recompleted in the Mesaverde. In 1996, a tubing repair was performed due to a hole in the tubing. Recently, in December of 1999, wireline was run and indicates another hole in the tubing. Current average production is 80 MCF/D. Anticipated uplift is 120 MCF/D for an estimated post-workover production rate of 200 MCF/D.


Tubing Repair Procedure:

1. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. Notify **BROG Regulatory (Peggy Cole 326-9727)** and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
2. MOL and RU workover rig. Hold safety meetings daily. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. ND WH and NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
3. 2-3/8" tubing is set at 6057'. Pick up additional joints of tubing and tag bottom. (Record depth.) PBTD should be at +/-6190'. TOO H with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build-up and notify Operations Engineer.
4. If fill is encountered, TIH with 3-7/8" bit, bit sub and watermelon mill on 2-3/8" tubing and round trip to PBTD, cleaning out with air/mist. **NOTE: When using air/mist, minimum mist rate is 12 bph.** If scale is present, contact Operations Engineer to determine methodology for removing scale from casing and perforations.
5. TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom then 1/2 of the 2-3/8" production tubing. Run a broach on sandline to insure that the tubing is clear. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace any bad joints. CO to PBTD with air/mist. PU above the perforations and flow the well naturally, making short trips for clean up when necessary.
6. Land tubing at ±6057'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. Obtain pitot gauge up the tubing. If well will not flow up the tubing, make swab run to SN. RD and MOL. Return well to production.

Recommended:


Operations Engineer

Approved:

 12-9-99
Drilling Superintendent

Operations Engineer:

Mike Haddenham
BR Office - 326-9577
Pager - 327-8427
Home - 326-3102

MDH/amm
12/8/99