

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells

<p>1. Type of Well GAS</p> <p>2. Name of Operator <b>BURLINGTON RESOURCES</b> OIL &amp; GAS COMPANY</p> <p>3. Address &amp; Phone No. of Operator PO Box 4289, Farmington, NM 87499 (505) 326-9700</p> <p>4. Location of Well, Footage, Sec., T, R, M 990' FNL, 1650' FEL, Sec. 31, T-30-N, R-7-W, NMPM</p>	<p>5. Lease Number NM-012709</p> <p>6. If Indian, All. or Tribe Name</p> <p>7. Unit Agreement Name San Juan 30-6 Unit</p> <p>8. Well Name &amp; Number San Juan 30-6 Unit #10</p> <p>9. API Well No. 30-039-07741</p> <p>10. Field and Pool Blanco Mesaverde</p> <p>11. County and State Rio Arriba Co, NM</p>
---	--

12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OTHER DATA

Type of Submission	Type of Action
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment <input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion <input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back <input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair <input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Altering Casing <input type="checkbox"/> Conversion to Injection
	<input checked="" type="checkbox"/> Other - Tubing repair

13. Describe Proposed or Completed Operations

It is intended to repair the tubing in the subject well according to the attached procedure.

RECEIVED  
JUL 10 1997  
OIL CON. DIV.  
DIST. 3

14. I hereby certify that the foregoing is true and correct.

Signed Wayne Townsend (ROS7) Title Regulatory Administrator Date 6/16/97

(This space for Federal or State Office use)

APPROVED BY WAYNE TOWNSEND Title \_\_\_\_\_ Date 7-8-97

CONDITION OF APPROVAL, if any:


**San Juan 30-6 Unit #10  
Blanco Mesaverde  
990' FNL, 1650' FEL  
NE Section 31, T-30-N, R-7-W  
Latitude / Longitude: 36°46.4163' / 107°36.5149'  
Recommended Tubing Repair Procedure**

1. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. **Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS.** As much time as possible to the pump time is needed for the Agency to be able to show up for the cement job.
2. MOL and RU workover rig. Blow well down. NU 7-1/16" 3000 psi (6" 900 series) BOP with stripping head. Test and record operation of BOP rams. Kill well with 1% KCL water only if necessary. Have christmas tree serviced as needed.
3. Release donut, pick up additional joints of tubing and tag bottom (record depth). TOOH with tubing. Visually inspect tbg for corrosion, and replace any bad joints. LD perf joint. Check tbg for scale and notify Operations Engineer.
4. TIH with casing scraper, bit and bit sub, and round trip to below perforations. TOOH. TIH with RBP on tubing and set at approximately 50' above top perf. Pressure test the casing to 500 psig. If pressure test fails, isolate leak and contact Operations Engineer for cement squeeze procedure.
5. Unload casing with air prior to releasing RBP. Release RBP and TOOH. TIH with tubing with an expendable check on bottom and a seating nipple one jt off bottom. Rabbit all tubing. CO to PBTD with air.
6. Land tubing near bottom perforation. ND BOP and NU wellhead. Pump off expendable check and record final gauges. Return well to production.

Recommended:

  
Operations Engineer

Approved:

  
Drilling Superintendent

Rob Stanfield Phone 326-9715  
Pager 324-2674