NO. OF COPIES RECEIVED	Form C-103
DISTRIBUTION	Supersedes Old C-102 and C-103
SANTA FE / NEW MEXICO OIL CONSERVATION COMMISSION	Effective 1-1-65
FILE / L	Low Indiana (During Co.)
U.S.G.S. LAND OFFICE	State Fed. Fee
OPERATOR 7	5. State Oli & Gao Lease No.
DIST. 3	
SUNDRY NOTICES AND REPORTS ON WELLS	
(DO NOT USE THIS FORM FOR PROPOSALS TO THILL ON TO DELPHON OR PLUS BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL GAS TO	7. Unit Agreement Name
WELL A OTHER-	San Juan 30-6 Unit
2. Name of Operator	8. Form or Lease Name
El Paso Natural Gas Company 3. Address of Operator	San Juan 30-6 Unit
	9. Well 130. 68 (OWWO)
PO Box 990, Farmington, NM 87401	10. Field and Pool, or Wildest
UNIT LETTER M . 1088 FEET FROM THE SOUTH LINE AND 989	Blanco Mesa Verde
UNIT LETTER 191 . 1000 FEET FROM THE BOULT LINE AND 707 FEET FROM	
THE West LINE, SECTION 25 TOWNSHIP 30N RANGE 6W NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.) 6732 DF	12. County
16. 0732 DF	Rio Arriba
Check Appropriate Box To Indicate Nature of Notice, Report or Oth	er Data
NOTICE OF INTENTION TO: SUBSEQUENT	REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON COMMENCE DRILLING OPNS.	PLUG AND ABANDONMENT
PULL OR ALTER CASING CHANGE PLANS CASING TEST AND CEMENT JOB OTHER	
OTHER Case cement and sandwater frac	
17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including work) SEE RULE 1703.	estimated date of starting any proposed
In order to increase production it is planned to workover and restimulate this well in the	
following manner:	
Pull tubing, set a drillable bridge plug near the bottom of the 7" casing and pressure	
test to 1000 psi.	
If tubing is stuck, cut off tubing approximately 100' below the 7" casing shoe, set a	
drillable cement retainer near the bottom of the 7" casing, squeeze the	
approximately 200 sks. of cement.	
Pressure test the 7" casing to 1000 psi.	
Isolate and squeeze cement any leaks. If leaks are squeezed near the base of the Ojo	
Alamo formation, no additional block squeeze of the 7" annulus is plant	
If there are no leaks near the base of the Ojo Alamo formation, perforate 2 squeeze	
holes at the base of the Ojo Alamo formation and block squeeze the 7" annulus with	
approximately 125 sks. of cement.	Illiand Willi
Clean out if hole conditions permit, otherwise sidetrack and redril	1 to approximately 6290'
Run a full string of 4 1/2" production casing and sufficient amount	
the 7" casing shoe. Selectively perforate and sand-water fracture the	
the / casing shoe. Selectively periorate and sand-water fracture the	wesa verde formation.
	· · · · · · · · · · · · · · · · · · ·
18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
Downlaum Frainces	July 26 1072
SIGNED TITLE Petroleum Engineer	July 26, 1972
01/0/10	
APPROVED BY WIRE DENGLINE THE INTECTE SECTIONS OF ME	TATE BEST AS T
CONDITIONS OF APPROVAL, VE ANY:	