

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name San Juan 30-5 Unit
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name San Juan 30-5 Unit
3. Address of Operator Box 990, Farmington, New Mexico - 87401	9. Well No. 21 (P & A)
4. Location of Well UNIT LETTER K 1650 FEET FROM THE South LINE AND 1700 FEET FROM THE West LINE, SECTION 24 TOWNSHIP 30N RANGE 5W NMPM.	10. Field and Pool, or Wildcat Blanco Mesa Verde
15. Elevation (Show whether DF, RT, GR, etc.) 7030' GL	12. County Rio Arriba

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOB	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Because of non-production it is planned to plug and abandon this well as follows:


Kill well and unseat hookwall packer. Spot a 50 sack cement plug on bottom (est. at 450' fill up).

Pull tubing to 3000' and spot a 200 sack cement plug to cover corroded casing 2 (Est. at 900' fillup), pull tubing.

Determine free point of 7 5/8" casing, shoot off above free point and spot a 50 sack cement plug on casing stub by displacing down freed casing, pull casing.

Spot a 25 sack cement plug at the base of surface casing. Place a 15 sack cement plug with a 4' x 4" P & A marker.

Clean and level location.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED E. H. Wood TITLE Petroleum Engineer DATE 4-10-69

APPROVED BY [Signature] TITLE Sup. R. T. III DATE 4-11-69
CONDITIONS OF APPROVAL, IF ANY: