UNITED STATES

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

Sundry Noti	ces and Reports on Wells				
	070 FARMMOTO	5.	Lease Number		
1. Type of Well GAS	070 FARMINGTON, NM	6.	SF-080713B If Indian, All. or Tribe Name		
2. Name of Operator		7.	Unit Agreement Name		
BURLINGTON	GAS COMPANY		San Juan 30-6 Unit		
3. Address & Phone No. of Operat		8.			
PO Box 4289, Farmington, NM		9.	API Well No. 30-039-07831		
4. Location of Well, Footage, Se 988'FSL, 899'FWL, Sec.14, T-3			Field and Pool Blanco Mesaverde County and State Rio Arriba Co, NM		
12. CHECK APPROPRIATE BOX TO IND		, OTHER	DATA		
Type of Submission _X_ Notice of Intent Subsequent Report	Type of Action Abandonment Change Recompletion New O Plugging Back Non-H	Construct			
Final Abandonment		Shut of	f		
13. Describe Proposed or Compl	eted Operations				
It is intended to repair t procedure and wellk	he tubing in the subject well core diagram.	accordin	ng to the attached		
	e descriptions of	general months granded by the grand and an ex-	contras is an existencia		
		CEN UL 3 1 18	VED 1997		
		CON.	. DIV. 3		
14. I hereby certify that the Signed Jugay Mulhus	foregoing is true and correct.				
(This space for Federal or State APPROVED BY /5/ Duage W. Space	Office use) Title	Date •	RIL 29 1997		

San Juan 30-6 Unit #42 Blanco Mesaverde 988' FSL, 899' FWL SW Section 14, T-30-N, R-6-W

Latitude / Longitude: 36°48.4763' / 107°26.2592'
Recommended Tubing Repair Procedure

- 1. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS. As much time as possible to the pump time is needed for the Agency to be able to show up for the cement job.
- MOL and RU workover rig. Blow well down. NU 7-1/16" 3000 psi (6" 900 series) BOP with stripping head. Test and record operation of BOP rams. Kill well with 1% KCL water only if necessary. Have wellhead and valves serviced as needed.
- 3. Release donut, pick up additional joints of tubing and tag bottom (record depth). TOOH with tubing. Visually inspect tbg for corrosion, and replace any bad joints. Check tbg for scale and notify Operations Engineer.
- 4. TIH with casing scraper, bit and bit sub, and round trip to below perforations. TOOH. TIH with RBP on tubing and set at approximately 50' above top perf. Pressure test the casing to 500 psig. If pressure test fails, isolate leak and contact Operations Engineer for cement squeeze procedure.
- 5. Unload casing with air prior to releasing RBP. Release RBP and TOOH. TIH with tubing with an expendable check on bottom and a seating nipple one jt off bottom. Rabbit all tubing. CO to COTD with air.
- 6. Land tubing near bottom perforation. ND BOP and NU wellhead. Pump off expendable check and record final gauges. Return well to production.

Recommended:

Operations Engineer

Approved:

Drilling Superintendent

Rob Stanfield Phone 326-9715


Pager 324-2674

San Juan 30-6 Unit #42

CURRENT

Blanco Mesaverde

988' FSL, 899' FWL, SW Section 14, T-30-N, R-06-W, Rio Arriba County, NM Latitude/Longtitude: 36°48.4763' / 107°26.2592'



Initial Poter	Initial Potential		Production History	<u>Gas</u>	<u>Oil</u>	Ownership		<u>Pipeline</u>
Initial AOF: 2 Current SICP:	2,593 Mcfd 445 psig	(11/56) (5/93)	Cumulative: Current: 5/97	865.7 MMcf 43.90 Mcfd	0.00 Mbo 0.00 bbls/d	GWI: NRI: TRUST:	34.39% 27.99% 3.66%	WFS