## UNITED STATES

## DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

	ces and Reports on Well		
	\$3 Jul	13 M 2: C3.	Lease Number SF-079002
. Type of Well GAS	G70 [5]:	11.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.	If Indian, All. or Tribe Name
No. of Opensham		7.	Unit Agreement Name San Juan 30-6 Unit
Name of Operator  BURLINGTON  RESOURCES OIL &	GAS COMPANY		Juli Guan Go G Gille
. Address & Phone No. of Operato		8.	Well Name & Number San Juan 30-6 Unit#
PO Box 4289, Farmington, NM		9.	<b>API Well No.</b> 30-039-07886
Location of Well, Footage, Sec. 1790'FNL 1600'FEL, Sec. 8, T-30			Field and Pool Blanco Mesaverde County and State Rio Arriba Co, NM
12. CHECK APPROPRIATE BOX TO IND	ICATE NATURE OF NOTICE	, REPORT, OTHER	DATA
Type of Submission	Type of Ac	tion	
_X_ Notice of Intent		Change of Pl	
	Recompletion	New Construc	tion
Subsequent Report	Plugging Back		
_, , , ,	Casing Repair _ Altering Casing		
Final Abandonment	Aftering Casing _ _X_ Other - tubing re		o injection
13. Describe Proposed or Compl	eted Operations		
It is intended to repair to attached procedure.	he tubing on the subje	ct well, accord	ing to the
It is intended to repair t	he tubing on the subje	ct well, accord	ing to the
It is intended to repair t	he tubing on the subje	ct well, accord	ing to the
It is intended to repair t	he tubing on the subje	ot well, accord	ing to the
It is intended to repair t	he tubing on the subje	DECE	
It is intended to repair t	he tubing on the subje	OIL COM	1VED 1998
It is intended to repair t	he tubing on the subje	DECE N jul 2 (	1VED 1998
It is intended to repair to attached procedure.	he tubing on the subje	DECE N JUL 2 ( OIL COM DIST.	1VED 1998
It is intended to repair t	he tubing on the subje	DECE N JUL 2 ( OIL COM DIST.	1VED 1998
It is intended to repair to attached procedure.	he tubing on the subje	DECE JUL 2 ( OIL COM DIST.	1998 DUV.

## San Juan 30-6 Unit # 36

Mesa Verde 1700'N, 1600'E

Unit G, Section 08, T-30-N, R-06-W

Latitude / Longitude: 36° 49.76' / 107° 28.93'

DPNO: 69759 Tubing Repair Procedure

- Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
- 2. MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and record operation of BOP rarns. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
- Mesa Verde, 2-3/8", 4.7#, J-55 tubing is set at 5612'. Release donut. pick up additional joints of tubing and tag bottom. (Record depth.) PBTD should be at +/- 5660'. TOOH with tubing. Visually inspect tubing for corrosion and replace any bas joints. Check tubing for scale build up and notify Operations Engineer.
- 4. If fill, TIH with 3-7/8" bit and bit sub on 2-3/8" and round trip to below perforations, cleaning out with air/mist. NOTE: When using air/mist, minimum mist rate is 12 bph. If scale is present, TIH with mill through perforations. TOOH with mill.
- 5. TIH with one joint of 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom then ½ of the 2-3/8" production tubing. Run a broach on sandline to insure that the tubing is clear. TIH with remaining 2-3/8" tubing and then broach this tubing. Replace any bad joints. CO to PBTD with air/mist. PU above the perforations and flow the well naturally, making short trips for clean up when necessary.

6. Land tubing at 5540'. ND BOP and NU WH. Pump off expendable check. Connect to casing and circulate air to assure that expendable check has pumped off. Obtain pitot gauge up the tubing. If well will not flow on it's own, make swab run to SN. RD and MOL. Return well to production.

Recommended:

Operations Engineer

Approved:

Drilling Superintendent

Mike Haddenham

Office - (326-9577)

Home - (326-3102)

Pager - (327-8427)

Production Foreman - Bruce Voiles

Office - (326-9571)

Pager - (326-8842)