


NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION



Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
2. Name of Operator El Paso Natural Gas Company	5. State Oil & Gas Lease No.
3. Address of Operator Box 990, Farmington, New Mexico 87401	7. Unit Agreement Name San Juan 30-5 Unit
4. Location of Well UNIT LETTER H, 1650 FEET FROM THE North LINE AND 990 FEET FROM THE East LINE, SECTION 8 TOWNSHIP 30-N RANGE 5-W NMPM.	8. Farm or Lease Name San Juan 30-5 Unit
15. Elevation (Show whether DF, RT, GR, etc.) 6348' GL	9. Well No. 20 (P & A)
	10. Field and Pool, or Wildcat Blanco Mesa Verde
	12. County Rio Arriba

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-production it is planned to plug and abandon this well in the following manner:

Kill well and circulate.

Run tubing and spot 75 sacks cement across perforated interval.

Determine free point by stretch. Shoot casing off at free point and spot a 30 sack cement plug on stub by displacing down the casing.

Pull 7 5/8" casing. Place a 25 sack cement plug across base of surface casing.

Place a 15 sack cement plug at surface, install a dry hole marker and clean location.

Note: If free point is above the top of the Ojo Alamo(2249') perforate at 2549'(base of Ojo Alamo) before shooting casing off and spot a 50 sack cement plug inside the 7 5/8" casing at 2549' and pressure displace through perforations about 20 sacks.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed F. H. WOOD

SIGNED _____ TITLE Petroleum Engineer DATE 7-29-70

APPROVED BY Emmy Alameda TITLE SUPERVISOR DIST. #3 DATE JUL 29 1970

CONDITIONS OF APPROVAL, IF ANY: