## UNITED STATES

## DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

zalli notice and nope	orts on Wells		
		<del>)</del>	Lease Number
			SF-080713-A
1. Type of Well	MA CONTRACT		If Indian, All. or
GAS	to the second se		Tribe Name
2. Name of Operator		7.	Unit Agreement Name San Juan 30-6 Unit
_			buil buail 50 0 onite
BURLINGTON RESOURCES OIL & GAS COMPAN	72		
OIL & GAS COMPAN	ĭ	8.	Well Name & Number
3. Address & Phone No. of Operator		٥.	San Juan 30-6 Unit#102
PO Box 4289, Farmington, NM 87499 (505)	) 326-9700	9.	API Well No.
			30-039-20519
4. Location of Well, Footage, Sec., T, R, M			Field and Pool
1720'FNL 1490'FEL, Sec.22, T-30-N, R-6-W	, NMPM		Blanco Mesaverde
		11.	County and State Rio Arriba Co, NM
			RIO AITIDA CO, MM
	Repair Water Shing Casing Conversi	on to	Injection
	ng Casing Conversi - tubing repair ions	on to	Injection
X_ Other 13. Describe Proposed or Completed Operation	ng Casing Conversi - tubing repair ions	on to	Injection
It is intended to repair the tubing of	ng Casing Conversi - tubing repair ions n the subject well, ac	on to	Injection  ng to the
It is intended to repair the tubing of	ng Casing Conversi - tubing repair ions n the subject well, ac	cordi	Injection  ng to the
It is intended to repair the tubing of	ng Casing Conversi - tubing repair ions n the subject well, ac	cordi	Injection  ng to the
It is intended to repair the tubing of	ng Casing Conversi - tubing repair ions n the subject well, ac	cordi	Injection  ng to the
It is intended to repair the tubing of	ng Casing Conversi - tubing repair ions n the subject well, ac	cordi	Injection  ng to the
It is intended to repair the tubing of	ng Casing Conversi - tubing repair ions n the subject well, ac	cordi	Injection  ng to the
It is intended to repair the tubing of	ng Casing Conversi - tubing repair ions n the subject well, ac	cordi	Injection  ng to the
It is intended to repair the tubing of	ng Casing Conversi - tubing repair ions n the subject well, ac	cordi	Injection  ng to the
It is intended to repair the tubing of	ng Casing Conversi - tubing repair ions n the subject well, ac	cordi	Injection  ng to the
It is intended to repair the tubing of	ng Casing Conversi - tubing repair ions n the subject well, ac	cordi	Injection  ng to the
It is intended to repair the tubing of	ng Casing Conversing tubing repair ions  In the subject well, according to the subject well, according to the subject well.	cordi	Injection  ng to the
It is intended to repair the tubing of attached procedure.	ng Casing Conversion tubing repair  ions  In the subject well, according to the subject well according to the	cordi	Injection  ng to the
It is intended to repair the tubing of attached procedure.  It hereby cerbify that the foregoing i	ng Casing Conversion tubing repair  ions  In the subject well, according to the subject well according to the subject we	cordi	Injection  Injection  Ing to the

## San Juan 30-6 Unit # 102R

Mesa Verde 1720'N, 1490'E

Unit G, Section 22, T-30N-N, R-06-W Latitude / Longitude: 36° 48.03' / 107° 26.75'

DPNO: 69832 **Tubing Repair Procedure** 

- Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental 1. regulations. Test rig anchors and build blow pit prior to moving in rig. Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS. Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
- MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well 2. down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
- Mesa Verde, 2 3/8", 4.7#, J-55 tubing is set at 6145'. Release donut, pick up additional joints of 3. tubing and tag bottom. (Record depth.) PBTD should be at +/- 6160'. TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
- If fill, TIH with 3-7/8" bit and bit sub on 2 3/8" tubing and round trip to below perforations, 4. cleaning out with air/mist. NOTE: When using air/mist, minimum mist rate is 12 bph. If scale is present, TIH with mill through perforations. TOOH with mill.
- TIH with one joint of 2 3/8" tubing with an expendable check on bottom and a seating nipple one 5. joint off bottom then ½ of the 2 3/8" production tubing. Run a broach on sandline to insure that the tubing is clear. TIH with remaining 2 3/8" tubing and then broach this tubing. Replace any bad joints. CO to PBTD with air/mist. PU above the perforations and flow the well naturally, making short trips for clean up when necessary.

Land tubing at 6050'. ND BOP and NU WH. Pump off expendable check. Connect to casing 6. and circulate air to assure that expendable check has pumped off. Obtain pitot gauge up the tubing. If well will not flow on it's own, make swab run to SN. RD and MOL. Return well to production.

Recommended: //

Operations Engineer

Approved:

Bruce D Bong 5-20-99
Drilling Superintendent

Mike Haddenham

Office - (326-9577)

Home - (326-3102)

Pager - (327-8427)

Production Foreman – Bruce Voiles

Office - (326-9571)

Pager - (326-8842)

MDH/ssv